


JVC

01590

SERVICE MANUAL

COMPACT DISC CHANGER

XL-M508BK
XL-M509TN




COMPU LINK
/// Remote ///
Control Component

Contents

Safety Precautions	1-2	Initial Operation Mechanism	1-43
Important for Laser Products	1-3	Operation check by each switch	1-46
Instruction Book	1-4	Flow of Functional Operation	
Description of Major LSIs	1-30	Until TOC is Read	1-47
Internal Block Diagrams of Other ICs	1-37	Troubleshooting	1-48
Internal Connection		Block Diagrams	Insertion
for the FL Display Tube ...	1-38	Schematic Diagrams	Insertion
Disassembly Procedures	1-39	Exploded View of Assemblies and	
Adjustment Procedures	1-41	Application Points for Grease ..	Insertion
Maintenance of Laser Pickup	1-42	Parts list	Insertion
Replacement of Laser Pickup	1-42		

Safety Precautions

1. The design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by () on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.
5. Leakage current check (Electrical shock hazard testing)
After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.
Do not use a line isolation transformer during this check.
 - Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.).
 - Alternate check method
Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500Ω 10 W resistor paralleled by a 0.15 μF AC-type capacitor between an exposed metal part and a known good earth ground.
Measure the AC voltage across the resistor with the AC voltmeter.
Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor.
Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75 V AC (r.m.s.).
This corresponds to 0.5 mA AC (r.m.s.).



Warning

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

Important for Laser Products

1. CLASS 1 LASER PRODUCT
2. DANGER : Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. CAUTION : There are no serviceable parts inside the Laser Unit. Do not disassemble the Laser Unit. Replace the complete Laser Unit if it malfunctions.
4. CAUTION : The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent emission of radiation when the drawer is open and the safety interlocks have failed or are defeated. It is dangerous to defeat the safety switches.
5. CAUTION : If safety switches malfunction, the laser is able to function.
6. CAUTION : Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
7. CAUTION : The compact disc player provides a laser diode of wavelength 780-790nm and optical output power typical 3mW at the laser diode.

VARNING : Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.

VARO : Avattaessa ja suojalukitus ohitettaessa olet alttina näkymättömälle lasersäteilylle. Älä katso sääteeseen.

ADVARSEL : Usynlig laserstrålning ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

ADVARSEL : Usynlig laserstrålning ved åpning, når sikkerhetsbryteren er avslott. unngå utsettelse for stråling.

REPRODUCTION AND POSITION OF LABELS

WARNING LABEL


(Except for the U. S. A.)

DANGER: invisible laser radiation when open and interlock failed or defeated.
AVOID DIRECT EXPOSURE TO BEAM. (e)

VARNING: Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen. (s)

ADVARSEL: Usynlig laserstrålning ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgådsættelse for stråling. (d)

VARO: Avattaessa ja suo-
jalukitus ohitettaessa olet alttina näkymättömälle lasersäteilylle. Älä katso sääteeseen. (f)



CLASS 1
LASER PRODUCT

CLASSIFICATION LABEL
(Except for the U. S. A. and Canada)

Introduction

We would like to thank you for purchasing one of our JVC products.

Before connecting this unit to the wall outlet, please read the instructions carefully to ensure that you obtain the best possible performance.

If you have any questions, please consult your JVC dealer.

This manual is organized as follows:

The first part of this manual, "PRECAUTIONS", tells you where to place this unit for best results, how to prevent malfunctions and what types of discs can be used in this unit.

The second part, "BEFORE USING FOR THE FIRST TIME", tells you what kind of operations you should do before playing a disc. This part describes how to install batteries in the remote control unit and how to connect this unit to the amplifier and other components.

The third part, "LOCATION OF BUTTONS", shows the names of buttons and their location and gives you basic knowledge of the functions of buttons on the main unit and the remote control unit. Refer to the section on the indicated page for each button.

The fourth part, "BASIC OPERATIONS", describes how to load discs, and convenient basic functions for playing discs.

The fifth part, "VARIOUS PLAYBACK PATTERNS", describes various functions for playing discs, and convenient functions for recording.

The sixth part, "DISC TITLE MEMORY BANK" describes the disc title memory bank function which is useful for locating a desired disc among the discs stored in the magazines.

The seventh part, "APPENDIX", describes the compu link remote control system which facilitates various operations between JVC components, and explains how to take care of discs and magazines.

The eighth part, "TROUBLESHOOTING", tells you how to check the unit if a malfunction occurs.

The ninth part, "SPECIFICATIONS", gives you technical information regarding this unit and tells you what accessories you have.

Contents

PRECAUTIONS	2
Installation	2
Preventing malfunctions	2
Applicable discs	2
BEFORE USING FOR THE FIRST TIME	3
Installing batteries in the remote control unit	3
Connections	3
Audio signal output jacks	4
Control signal output/input jacks for Compu Link Remote	4
Control System	4
AC power supply	4
LOCATION OF BUTTONS	5
Main unit	5
Remote control unit	6
Disc playback mode	6
Disc title memory bank mode	7
BASIC OPERATIONS	8
Preliminary operations before playing a disc	8
Turning on the power of this unit	8
Loading a disc in the single disc tray	8
Loading discs in the magazine	8
Inserting the magazine	9
Basic functions for disc playback	9
Playing a disc	9
Stopping playback	9
Searching for a desired track or section	10
Specifying a desired track or tape playing time	10
Specifying a desired disc	11
Switching the time display	11
Switching the playback mode	11
Remote control operation	11
VARIOUS PLAYBACK PATTERNS	12
Guidance for various functions	12
CONTINUE PLAY	12
RANDOM PLAY	13
PROGRAM PLAY	13
DELETE PROGRAM PLAY	14
INTRO SCAN	15
Disc intro scan	15
Track intro scan	15
REPEAT	16
REPEAT ALL	16
REPEAT 1	16
EDIT	16
PROGRAM EDIT	16
INTRO EDIT	17
DISC TITLE MEMORY BANK	19
TITLE INPUT	19
DISC SEARCH	20
TITLE SEARCH	20
APPENDIX	21
Compu link remote control system	21
Care of discs and magazines	22
TROUBLESHOOTING	23
SPECIFICATIONS	24

PRECAUTIONS

Installation

Best location

Select a location which is level, dry and neither too cold nor too hot (temperature range 5°C (41°F) to 35°C (95°F)). Also, avoid dusty locations or any location subject to vibration.

If interference occurs

If this equipment is placed near a tuner or a radio receiver tuned to AM frequencies, interference may occur. If this happens, we recommend either that you move this unit as far away as possible from the tuner or receiver or briefly turn off the power to this unit.

Preventing malfunctions

Load compact discs only

Never insert anything other than a compact disc into any part of the player or magazine.

If a problem persists

If something goes wrong, turn the power off immediately. If the same problem reoccurs when the power is turned on once more, turn the power off again and consult your JVC dealer.

Handling the power cord

When unplugging from the wall socket, always pull the plug body, never the power cable.

Volume settings

A CD player has almost zero background noise. Because of this, the technique of listening to the background level and then setting the volume before the music starts, as used with analog turntables or tape decks, cannot be used. If you raise the volume level too high, speaker damage may result.

Condensation

The CD player uses optical components. If it is moved from a cold location to a warm one, or is used in a room subject to excessive humidity or where a fire has just been lit, condensation could form on the optical components.

This may prevent the laser beam from being properly transmitted and thus cause noise or even a malfunction.

If condensation has formed and the CD player does not function correctly, we recommend that you leave it turned on for an hour or two. If at the end of this time the CD player still does not function properly, please consult your JVC dealer.

Transporting the unit

When carrying this unit, it is best to avoid either tilting it or turning it upside-down. Where you cannot avoid doing so, please remove the disc and magazine first.

Using compact discs

Compact discs are made of plastic and can be easily damaged. If the disc is dirty, scratched, warped or otherwise damaged, the digital information may not be picked up correctly.

Applicable discs

This unit can only be used with compact discs bearing the mark below. Never use other types of discs.




BEFORE USING FOR THE FIRST TIME


Installing batteries in the remote control unit

Before operating the remote control unit, install two batteries.


1. Remove the rear cover of the remote control unit by pressing down and simultaneously pulling it backwards.



2. Install batteries. Be sure batteries are installed with correct polarity, (+) and (-).



3. Attach the rear cover by sliding it back into position.



Notes

Incorrect use of batteries can cause corrosion or damage. Note the following points to lengthen battery life.

- Install batteries observing the correct polarity, (+) and (-).
- Do not use new and old batteries simultaneously.
- Batteries with similar shapes may have different voltage ratings. Be sure to use the correct batteries.
- Remove batteries from the remote control unit if it will not be used for a long period of time.

Battery replacement

Service life of batteries depends on the condition of use; standard life is about one year. When the batteries become weak, the operating distance of the remote control unit becomes short and the brightness of the indicators on the remote control unit is reduced. If this happens, replace the batteries (1.5 V, R6P, size AA) with new ones.


Notes

- The lower the temperature, the shorter the battery life.
- Be sure to replace the batteries within 3 minutes. Otherwise, the stored contents in disc title memory bank are erased.

Connections

This diagram shows a typical connection.

Remove the caps of the OPTICAL DIGITAL OUTPUT jack and optical fiber cable.



Notes on connections

- Do not connect the power plug until all connections are completed.
- Connect the plugs firmly. Loose connections may cause noise or malfunction.

BEFORE USING FOR THE FIRST TIME

Audio signal output jacks

The audio signals are output from these jacks. Connecting to an amplifier or receiver allows you to listen to the sound from the speakers.

There are two ways to connect an amplifier or receiver; with the analog OUTPUT jacks and OPTICAL DIGITAL OUTPUT jack.

(A) OPTICAL DIGITAL OUTPUT jack

For digital connections, connect the OPTICAL DIGITAL OUTPUT jack of this unit to the optical digital input jack of the amplifier or receiver with the following method.

1. Remove the protective dust cap from the OPTICAL DIGITAL OUTPUT jack of this unit and the optical digital input jack of the amplifier or receiver.
2. Connect the OPTICAL DIGITAL OUTPUT jack and input jacks with the optional optical fiber cable.

Notes

- Be sure to use the amplifier or receiver which uses the same type of optical transmission/reception module.
- Be careful not to fold or crimp the cable. When coiling an optical fiber cable for storage, make sure that the diameter of the coil is 15 cm (6 inches) or larger.
- Use an optical fiber cable with a length of 3 m (9 feet) or less.
- Protect the optical fiber cable plugs from scratches and dust.
- When the unit is not connected using an optical fiber cable, be sure to keep the protective dust cap plugged into the optical digital output jack at all time.

(B) Analog OUTPUT jacks

For analog connections, connect the OUTPUT jacks of this unit to the CD jacks or AUX input jacks of an amplifier or receiver with the supplied audio cable.

Notes

- Never connect the OUTPUT jacks to the PHONO jacks of the amplifier or receiver. This may cause damage to the components.
- Make sure that the same channels are connected between this unit and the amplifier or receiver: LEFT to LEFT and RIGHT to RIGHT.

Control signal output/input jacks for Compu Link Remote Control System

(C) COMPU LINK SYNCHRO jaks

These jacks are used to output and input the control signal for the compu link remote control system. Connecting JVC audio components with the COMPU LINK SYNCHRO jacks automatically controls relative operations between components and facilitates various operations.

Connect the COMPU LINK SYNCHRO jacks of this unit and JVC components with the supplied remote cable. Since each component has two COMPU LINK SYNCHRO jacks (there is no difference between the two jacks), you can connect two components to these jacks.

Notes

- It is necessary to connect the analog OUTPUT jacks even when the OPTICAL DIGITAL OUTPUT jack is connected.
- Make sure that the COMPU LINK SYNCHRO jacks of the individual components are connected with the supplied remote cables. Also, be sure to fully read the instructions for each component.

AC power supply

(D) AC POWER CORD inlet

The AC power cord is supplied separately and must be connected to the unit.


Plug the power cord into the AC POWER CORD inlet of this unit and connect to an AC household electrical outlet after all connections are completed.

Note

When using the Compu Link Remote Control System version 3, do not connect the power cord to the SWITCHED AC OUTLET of an amplifier or receiver. Otherwise, the automatic power on/off function cannot be carried out.

LOCATION OF BUTTONS

Main unit



The operation for each button is described in the section indicated with the → mark.

1 POWER (ON/STANDBY) switch and STANDBY indicator

→ "Turning on the power of this unit" on page 8.
To turn off the power completely, disconnect the power cord from the wall outlet.

2 REMOTE SENSOR

→ "Remote control operation" on page 11.

3 Display window

This shows disc status information.

4 Disc magazine slot

Insert the magazine into this slot.
→ "Inserting the magazine" on page 9.

5 Track buttons

→ "Specifying a desired track or tape playing time" on page 10.

6 EJECT ▲ button

→ "Inserting the magazine" on page 9.

7 EDITING and SIDE A/B buttons

These buttons are used to edit tracks.
→ "EDIT" on page 16.

8 MEMORY button

This button is used to memorize the disc number and/or track number in the following operation modes.
→ "PROGRAM PLAY" on page 13.
→ "DELETE PROGRAM PLAY" on page 14.
→ "EDIT" on page 16.

9 CALL button

This button is used to display the program contents in the following operation modes.
→ "PROGRAM PLAY" on page 13.
→ "DELETE PROGRAM PLAY" on page 14.
→ "EDIT" on page 16.

10 PLAY MODE button

→ "Switching the playback mode" on page 11.

11 PLAY ▶/II PAUSE button

→ "Playing a disc" on page 9.

12 STOP ■ /CANCEL button

→ "Stopping playback" on page 9.

13 SEARCH ▲/▼/◀/▶ buttons

→ "Searching for a desired track or section" on page 10.

14 OPEN/CLOSE ▲ button

→ "Loading a disc in the single disc tray" on page 8.

15 DISC buttons

→ "Specifying a desired disc" on page 11.

16 Single disc tray

Load a disc in this disc tray.
→ "Loading a disc in the single disc tray" on page 8.

17 INTRO button

This button is used to carry out the intro scan function.
→ "INTRO SCAN" on page 15.

18 REPEAT ALL/1 button

This button is used to carry out the repeat function.
→ "REPEAT" on page 16.

19 DISPLAY button

→ "Switching the time display" on page 11.

20 PHONES jack and PHONES LEVEL control

Insert the headphones plug into the jack and turn the control to adjust the volume level.

LOCATION OF BUTTONS


Remote control unit

This remote control unit is used in disc playback mode and disc title memory bank mode.

The operation for each button is described in the section indicated with the → mark.

Disc playback mode

In disc playback mode, use the buttons with names colored white.



(A) Transmit indicator

This indicator briefly lights when the remote control unit transmits the signal.

(B) Operation display

This shows the operation of the pressed button.

(C) POWER button

→ "Turning on the power of this unit" on page 8.

(D) TRACK buttons

→ "Specifying a desired track or tape playing time" on page 10.

(E) DISC buttons

→ "Specifying a desired disc" on page 11.

(F) Basic control buttons

■: Press to stop play temporarily.
To resume playback, press the ▶ button.

▶: Press to start playback.

■: Press to stop playback.

M. EJECT△: Press to eject the magazine.

OPEN/CLOSE ▲: Press to open or close the single disc tray.

AUTO SEARCH ▲◀▶: Press to skip to the previous track or next track.

(G) Play mode buttons

→ "Switching the playback mode" on page 11.

(H) CALL button

This button is used to display the program contents in the following operation modes.

→ "PROGRAM PLAY" on page 13.

→ "DELETE PROGRAM PLAY" on page 14.

→ "EDIT" on page 16.

(I) CANCEL button

This button is used to erase the displayed programmed track in the following operation modes.

→ "PROGRAM PLAY" on page 13

→ "DELETE PROGRAM PLAY" on page 14


→ "EDIT" on page 16

(J) Remote control signal transmit section

LOCATION OF BUTTONS

Disc title memory bank mode

In disc title memory bank mode, use the buttons with names colored orange or green. With the shift function, the buttons with names colored green can be used to enter a digit.



K Display

L TITLE SEARCH button

→ "TITLE SEARCH" on page 20.

M ENTER button

After specifying the magazine symbol, disc tray number or disc title, be sure to press this button.

N Alphabet buttons, digit buttons and space button

O SHIFT button

P CANCEL button

Press this button to cancel the displayed contents.

Q BEFORE and NEXT buttons

R ← and → buttons

S TITLE IN button

→ "TITLE INPUT" on page 19.

T DISC SEARCH button


→ "DISC SEARCH" on page 20.

BASIC OPERATIONS

Preliminary operations before playing a disc

Turning on the power of this unit

Press the POWER switch to turn on this unit.



Press again to turn the power off and the unit enters the standby mode.

The power is automatically turned on also by:


- pressing ▲ OPEN/CLOSE button,
- pressing ▲ EJECT button,
- pressing PLAY ▶/II PAUSE button,
- or inserting the disc magazine into the magazine slot.

Note

A small amount of power (3 watts) is consumed and the STANDBY indicator is lit in the standby mode. To turn the power off completely, disconnect the power cord from the wall outlet.

Loading a disc in the single disc tray

Use the OPEN/CLOSE ▲ button to open and close the single disc tray.



1. Open the single disc tray by pressing the OPEN/CLOSE ▲ button.
2. Place a disc on the disc tray according to the groove with its label side up.
3. Close the single disc tray by pressing the OPEN/CLOSE ▲ button.

Note

When loading a disc in the single disc tray, be sure to put the disc according to the groove. Otherwise, the disc will be damaged when the disc tray is closed, and the disc cannot be removed from the unit.


Auto close function

If the unit changes the disc in the magazine when the single disc tray is left open, the unit automatically closes the tray. The AUTO CLOSE indicator blinks for about 2 seconds before the unit closes the tray.

Loading discs in the magazine


When playing 2 discs or more, load discs in the magazine beforehand.

1. Slide the disc tray out while pressing the tray release button.



2. Place a disc on the disc tray with its label side up.

It is not possible to play a disc if it is inserted upside-down. Also, never place a disc directly in the magazine without using the disc tray.




3. Line up the disc tray with the grooves in the magazine and push the disc tray in.

It is unnecessary to press the tray release button when inserting the disc tray.

BASIC OPERATIONS

When inserting and removing the disc tray, be careful with the following.

- Never bend the disc tray or force it into the magazine.
A disc tray which is inserted skewed may cause a malfunction.



- When removing or inserting disc trays, the magazine should be held horizontal.
- The openings in the disc trays are for passage of the laser signal. These openings leave part of the shiny surface of the disc exposed. Please take care not to touch this shiny surface.

Optional magazines

If you wish to use 8 cm (3 inches) CDs, please obtain the special magazine (XC-M73) designed for these discs.


If you wish to use a magazine additionally to the supplied magazine, please obtain the special magazine (XC-M75) designed for 12 cm (5 inches) CDs.

Inserting the magazine

Insert a magazine, with discs loaded, into the 6-disc magazine slot and push it lightly until it clicks into place.

To remove the magazine, press the EJECT Δ button.

Main unit



Remote control unit



Caution

The player may be damaged if the magazine is pushed in with too much force.

Basic functions for disc playback


Playing a disc

Press the PLAY $\blacktriangleright/\text{II}$ PAUSE button of the main unit or \blacktriangleright button on the remote control unit.

Main unit



Remote control unit



The \blacktriangleright indicator lights on the display and playback starts.

To stop playback temporarily, press the PLAY $\blacktriangleright/\text{II}$ PAUSE button again or II button on the remote control unit.

The II indicator lights on the display and playback stops. To resume playback, press the PLAY $\blacktriangleright/\text{II}$ PAUSE button again or \blacktriangleright button on the remote control unit.

Stopping playback

Press the \blacksquare button.

Main unit




Remote control unit



BASIC OPERATIONS**Searching for a desired track or section**

Use the **◀◀/▶▶** buttons.

**To skip to a desired track during playback**

To skip back to the beginning of the track being played, tap the **◀◀** button. When the beginning of the track is reached, tapping this button again skips to the previous track.

To skip to the next track, tap the **▶▶** button.


To search for a desired section during playback

When the **◀◀** or **▶▶** button of the main unit is kept pressed, playback advances or reverses rapidly.

While the **◀◀** button is kept pressed, play rapidly reverses toward the beginning of the track. While the **▶▶** button is kept pressed, play rapidly advances toward the end of the track. When the desired section is reached, release the button. The player resumes normal playback from that point.

Specifying a desired track or tape playing time

To specify the desired track number, use the track buttons.



The unit searches for the selected track and playback starts automatically.

When selecting track number 10 or less, press the corresponding track button. When selecting track number 11 or above, use the **[+10]** button.

Example: To select track number 12, press **[+10]** and then **[2]**.

To select track number 25, press **[+10]** twice and then **[5]**.

To select track number 30, press **[+10]** twice and then **[10]**.

Note

If the selected track number does not exist on the selected disc, playback starts from the final track on that disc.


To specify the tape playing time

You can specify the tape playing time (in minutes) by following the procedure above.

BASIC OPERATIONS

Specifying a desired disc

Use the DISC buttons.



To specify the disc loaded in the single disc tray
Press the [P] button.


To select a disc loaded in the magazine
Press the desired disc number (1 - 6).

Note

If the selected disc is not loaded in the magazine, the indicator of that disc (—) goes out within about 4 seconds and then playback starts from the next disc.

Switching the time display

Use the DISPLAY button.



Each time the DISPLAY button is pressed, the display changes to the remaining play time, to the total playback time of the disc, and then back to the elapsed time display. The corresponding indicator lights in each time mode.


EACH: Shows the elapsed time of the track being played.

EACH REMAIN: Shows the remaining playback time of the track being played.

When the EACH and EACH REMAIN indicators go out: Shows the total playing time of the disc being played.

Switching the playback mode

Use the PLAY MODE button of the main unit or play mode buttons on the remote control unit. The playback mode can be switched only in stop mode.



Each time the PLAY MODE button of the main unit is pressed, the playback mode changes in the following order:

- CONTINUE PLAY (The CONTINUE indicator lights.)
- ↓ PROGRAM PLAY (The PROGRAM indicator lights.)
- ↓ RANDOM PLAY (The RANDOM indicator lights.)
- ↓ DELETE PROGRAM PLAY (The DEL. PRGM indicator lights.)

When using the play mode buttons on the remote control unit, press the corresponding play mode button.

Note

The setting of the playback mode is not canceled even when the unit enters standby mode.

Remote control operation

Point the remote control unit towards the REMOTE SENSOR and operate it steadily and carefully. The remote control unit can be used within a range of about 7 meters (23 feet) from the REMOTE SENSOR, and at angles of up to about 30 degrees.

VARIOUS PLAYBACK PATTERNS

Guidance for various functions

This unit has edit functions for recording and a disc title memory bank function in addition to various playback functions. Please read this section to familiarize yourself with this unit.

CONTINUE PLAY

You can continuously play from any track on any disc through the final track on disc number 6.

PROGRAM PLAY

You can play only the desired tracks in any desired order.

DELETE PROGRAM PLAY

You can play tracks other than undesired tracks in order of track number and disc number by programming the undesired tracks.

RANDOM PLAY

The unit selects and plays tracks at random from among all discs loaded in the unit.

INTRO SCAN

The disc intro scan function allows you to check all discs in the unit by playing the beginning of the first track on each disc.

The track intro scan function allows you to check all tracks on all discs in the unit by playing the beginning of each track.

REPEAT


You can play all discs or a track repeatedly.

EDIT

You can program tracks within the specified recording time of a cassette tape while listening to the beginning of each track (Intro edit) or by designating the track number (Program edit).

CONTINUE PLAY

In continuous playback mode, you can continuously play from any track on any disc through the final track on disc number 6. When discs are inserted into both the single disc tray and the magazine, the unit starts playback from the disc in the single disc tray.




1. Press the PLAY MODE button so that the CONTINUE indicator lights on the display.

When you want to play from a desired disc or track, go to step 3.

2. Press the PLAY ▶/II PAUSE button to start playback.

Playback starts from the first disc in the magazine (without loading a disc in the single disc tray) or the disc loaded in the single tray. If the single disc tray is not closed, pressing the PLAY ▶/II PAUSE button closes the disc tray and then starts playback. The following display appears.



3. Use the DISC button to select the disc number which contains the track to be played.

When you want to play from the first track on the selected disc, it is not necessary to select the track number.


4. Select the track number with the SEARCH ▲◀▶▼ buttons or track buttons.

The selected track number appears on the display and playback starts from the selected track automatically.

VARIOUS PLAYBACK PATTERNS

RANDOM PLAY

In random mode, the unit selects and plays tracks at random from among all discs loaded in the unit.
Selections are made so that each track is played only once.



1. Press the PLAY MODE button so that the RANDOM indicator lights on the display.
2. Press the PLAY ▶/II PAUSE button to start playback.


- To skip to the track to be next played, press the SEARCH ▶▶ button.
- To repeatedly play all tracks in random order, press REPEAT ALL/1 button so that the REPEAT indicator lights on the display.

To cancel random playback

Select other playback mode (CONTINUE, PROGRAM or DEL. PRGM) with the PLAY MODE button. The RANDOM indicator goes out and the unit enters the selected play mode.

PROGRAM PLAY

You can program up to 32 steps in any desired order from among the discs in the magazine and single disc tray.




As an example, the following steps show how to program track number 9 on disc number 2 and track number 3 on disc number 4 in this order.

1. In stop mode, press the PLAY MODE button so that the PROGRAM indicator lights on the display.
2. Use the DISC button to select the disc which contains the track to be programmed.
"AL" (all tracks) appears on the display.

To program the entire disc

Skip step 3 below. When the track number is not specified after selecting the disc number, all tracks on the displayed disc are programmed.

3. Select the track number with the track buttons.
Refer to "Specifying a desired track or tape playing time" on page 10 for entering the track number.
After selecting the track, the following display appears.



- If you want to cancel the displayed program step, press the STOP ■/CANCEL button and then enter the new disc number and/or track number.


VARIOUS PLAYBACK PATTERNS

DELETE PROGRAM PLAY

4. Select the disc number and track number to be programmed for step 2.

In this example, enter disc number 4 with the DISC button and then track number 3 with the track button.

After selecting the track, the following display appears.

**5. If necessary, repeat steps 2 and 3 for other tracks and/or discs to be programmed.****6. Start program playback with the PLAY ▶/PAUSE button.**

The programmed tracks and/or discs are played in the programmed order.

- You can skip to a desired program step with the SEARCH ←→ button.
- To repeatedly play the programmed tracks and/or discs, press the REPEAT ALL/1 button so that the REPEAT indicator lights on the display.

To check the program contents

Each time the CALL button is pressed, the program contents are displayed in the programmed order.

- When the unit is in program play mode, press the STOP ■/CANCEL button to enter stop mode and then operate the CALL button.

To modify the program contents

Press the CALL button until the display shows the program step to be corrected. Enter the new disc number and/or track number referring to steps 2 and 3 above.

To delete a program step, press the CALL button until the display shows the program step to be deleted and then press the STOP ■/CANCEL button. You can also delete a displayed program step during programming.

- When the unit is in program play mode, press the STOP ■/CANCEL button to enter stop mode and then delete the program step.


To exit program mode

Select another playback mode with the PLAY MODE button. The unit enters the selected playback mode. However, the program contents are not erased and whenever the program mode is selected with the PLAY MODE button, you can play the tracks in the programmed order.

To clear the entire program

Eject the magazine and open the single disc tray. The program contents will be cleared, however, the program mode is not canceled.

You can program undesired tracks and/or discs from among the discs in the 6-disc magazine and single disc tray. With this function, only the remaining tracks and/or discs are played. Up to 32 steps can be programmed.



As an example, the following steps show how to delete track number 9 on disc number 2 and track number 3 on disc number 4.

1. In stop mode, press the PLAY MODE button so that the DEL.PRGM indicator lights on the display.

2. Use the DISC button to select the disc number which contains the track to be deleted.
"AL," (all tracks) appears on the display.


To delete the entire disc

Skip step 3 below. When the track number is not specified after selecting the disc number, all tracks on the displayed disc are deleted.

3. Select the track number with the track buttons.

Refer to "Specifying a desired track or tape playing time" on page 10 for entering the track number.

After selecting the track number, the following display appears.




- If you want to cancel the displayed program step, press the STOP ■/CANCEL button and then enter the new disc number and/or track number.

VARIOUS PLAYBACK PATTERNS

4. Select the disc number and track number to be deleted for step 2.

In this example, enter disc number 4 with the DISC button and then track number 3 with the track button.



5. If necessary, repeat steps 2 and 3 for other tracks and/or discs to be deleted.

6. Start delete program playback with the PLAY ▶/PAUSE button.

All tracks other than deleted tracks and/or discs are played in the order of the disc and track numbers.

- You can skip to a desired track other than deleted tracks with the SEARCH \blacktriangleleft or \triangleright button.
- To repeatedly play the tracks and/or discs other than deleted tracks and/or discs, press the REPEAT ALL/1 button so that the REPEAT indicator lights on the display.

To check the delete program contents

Each time the CALL button is pressed, the delete program contents are displayed in the programmed order.

- When the unit is in delete program playback mode, press the STOP ■/CANCEL button to enter stop mode and then operate the CALL button.

To modify the delete program contents

Press the CALL button until the display shows the program step to be corrected. Enter the new disc number and/or track number referring to steps 2 and 3 above.

To erase a program step, press the CALL button until the display shows the program step to be erased and then press the STOP ■/CANCEL button. You can also erase a displayed program step during programming.


- When the unit is in delete program play mode, press the STOP ■/CANCEL button to enter stop mode and then delete the program step.

To clear the entire program

Change the playback mode with the PLAY MODE button or eject the magazine and single disc tray. The program contents will be cleared.

INTRO SCAN

You can use 2 types of intro scan functions (Disc intro scan and Track intro scan) to search for a desired disc or track.



Each time the INTRO button is pressed, the intro scan mode changes in the following order; Disc intro scan (DISC INTRO) → Track intro scan (INTRO) → Intro scan off → Disc intro scan. Make sure that the CONTINUE indicator is lit on the display. Otherwise, intro scan playback cannot be carried out.

Disc intro scan

In stop mode, press the INTRO button so that the DISC INTRO indicator lights on the display.

The beginning of the first track on each disc is played for about 15 seconds starting with the disc in single disc tray and continuing through to the 6th disc in the magazine. When the desired disc is reached, press the SEARCH \blacktriangleleft button. The disc intro scan mode is canceled and normal playback continues.

Track intro scan

In stop mode, press the INTRO button so that the INTRO indicator lights on the display.

The beginning of each track on each disc is played for about 15 seconds starting with the disc in single disc tray and continuing through to the 6th disc in the magazine. When the desired track is reached, press the SEARCH \blacktriangleleft button. The track intro scan mode is canceled and normal playback continues.


The following operations also cancel the intro scan mode.

- When the playback mode is changed with the PLAY MODE button.
- When the SEARCH \triangleright button, DISC button or track button is pressed.

VARIOUS PLAYBACK PATTERNS**REPEAT**

With the repeat functions, you can repeatedly play all discs or one track.

With the REPEAT ALL function, all discs are played repeatedly. To repeatedly play one track, use the REPEAT 1 function.

**REPEAT ALL**

Press the REPEAT ALL/1 button so that the REPEAT indicator lights on the display.

All discs loaded in the player are played repeatedly.

REPEAT 1

Press the REPEAT ALL/1 button so that the REPEAT 1 indicator lights on the display.

The displayed track number is played repeatedly.


To cancel repeat mode

Press the REPEAT ALL/1 button so that the REPEAT and REPEAT 1 indicators go out.

EDIT

With the edit functions, you can program the desired tracks within the specified recording time by observing the amount of recording time remaining as each track is programmed.

Up to 16 steps can be programmed for each side of a cassette tape. The programming cannot be carried out with track number 32 or above.

**PROGRAM EDIT**

You can program tracks from among discs in the unit by specifying the disc number and track number.

1. Press the EDITING button so that the PRGM EDIT indicator lights on the display.
2. Enter the tape playing time (in minutes) of your cassette tape. Refer to "Specifying a desired track or tape playing time" on page 10 for entering the time.

When 46 minutes is entered:




3. Select the disc which contains tracks to be programmed with the DISC number button.
4. Select the track number with the track buttons. Refer to "Specifying a desired track or tape playing time" on page 10 for entering the track number.
 - If you want to cancel the displayed program step, press the STOP ■/CANCEL button and then enter the new disc number and/or track number.

VARIOUS PLAYBACK PATTERNS

5. Repeat steps 3 and 4 for other tracks to be programmed.

6. When the remaining time is not long enough to program any more tracks, press the SIDE A/B button so that the SIDE-B indicator lights on the display and repeat steps 3 through 5.



- Once you program 16 steps, no more tracks can be programmed.

When total playing time of the programmed tracks has exceeded the specified time:

The excess time display blinks and no more tracks can be programmed. In this case, press the STOP ■/CANCEL button to delete the last programmed step so the tracks fit within the specified time.



INTRO EDIT

You can program tracks while listening to the beginning of each track on the selected disc.

1. In stop mode, press the EDITING button so that the INTRO EDIT indicator lights on the display.

2. Enter the tape playing time (in minutes) of your cassette tape. Refer to "Specifying a desired track or tape playing time" on page 10 for entering the time.

When 46 minutes is entered:



3. Select the disc which contains tracks to be programmed with the DISC number button.

Intro scan playback starts on the selected disc. The beginning of each track is played for about 15 seconds.

4. Press the MEMORY button when the desired track is reached.

When the MEMORY button is pressed, the track being played is programmed and the unit searches for the next track. Whenever a desired track is reached, you can program it by pressing the MEMORY button. In this way up to 16 steps can be programmed.

- With SEARCH ►► or ▲▲ button, you can skip to the desired track.

5. When the remaining time is not long enough to program any more tracks, press the ■ STOP/CANCEL button.

Intro scan playback stops and the display shows the last program step.



- Once you program 16 steps, intro scan playback stops and no more tracks can be programmed.

6. To program tracks for side B, press the SIDE A/B button so that the SIDE-B indicator lights on the display and repeat steps 3 through 5.

When total playing time of the programmed tracks has exceeded the specified time:

Intro scan playback stops and the excess time display blinks. In this case, press the STOP ■/CANCEL button to delete the last programmed step so that the tracks fit within the specified time.

VARIOUS PLAYBACK OPERATIONS

Operations after editing tracks

To record the programmed tracks

1. Set the cassette deck to record-standby mode.
2. Press the PLAY ▶/II PAUSE button to start edit program play.
If this unit and the cassette deck are connected with the COMPU LINK terminal, the cassette deck enters record mode automatically. When the program for side A finishes playing, this unit and cassette deck enter pause mode. Set the cassette deck for recording of side B, and press the PLAY ▶/II PAUSE button of this unit to start playback of side B. The cassette deck enters record mode automatically.

To check the program contents

Each time the CALL button is pressed, the program contents are displayed in the programmed order.

- When the unit is in playback mode, press the STOP ■/CANCEL button to enter stop mode and then operate the CALL button.

To modify the program contents

Press the CALL button until the display shows the program step to be corrected. Enter the new track number with the numeric buttons or the SEARCH ▲◀◀/▶▶ buttons. When the SEARCH ▲◀◀ or ▶▶ buttons is used, be sure to press the MEMORY button after selecting the track number.

To delete a program step, press the CALL button until the display shows the program step to be deleted and then press the STOP ■/CANCEL button.

- When the unit is in playback mode, press the STOP ■/CANCEL button to enter stop mode and then delete the program step.

To clear the entire program

Change the playback mode with the PLAY MODE button or eject the magazine and single disc tray. The program contents will be cleared.

DISC TITLE MEMORY BANK

Can you remember the titles of all the discs in the magazine? If you have more than one magazine and you always store discs in them, it may become difficult to find a desired disc. To solve this problem, we recommend using the disc title memory bank function as your memorandum.

Once the disc titles and their addresses are stored in the disc title memory bank of the remote control unit, you can easily find out which disc tray contains the desired disc. You can also check what discs exist in each magazine.

Guidelines for using the disc title memory bank are as follows.

Before using the disc title memory bank, attach the supplied label (A - Z) to each magazine. When entering the magazine symbol, you should use an alphabet according to the attached label.

● Disc title input

Enter the magazine symbol (A - Z) and disc tray number (1 - 6), and then enter the corresponding disc title.

● Disc address search - When you know the disc title but not the location.

The magazine symbol and disc tray number of a desired disc can be displayed by specifying one or more letters of the disc title. You can specify as many letters as required, starting from the first letter.

● Disc title search - When you wish to check what discs exist in a magazine.

By specifying the magazine symbol and disc tray number, the disc title of that tray can be displayed.

Note


The names and characters of buttons on the remote control unit used for disc title memory bank operations are colored orange and green.

TITLE INPUT


To utilize the disc title memory bank function, it is necessary to input the magazine symbol (A - Z), the disc tray number (1 - 6) and the corresponding disc title beforehand. Up to 8 characters (including digits) can be used for each disc title and up to 156 disc titles (6 discs x 26 magazines) can be stored in memory.

1. Press the TITLE IN button.


The unit enters title input mode and the TITLE INPUT indicator lights in the display.



2. Specify the magazine symbol (A - Z) with the alphabet buttons and press the ENTER button.



3. Specify the disc tray number (1 - 6) with the DISC button and press the ENTER button.



4. Specify the disc title with the alphabet buttons and/or digit buttons and press the ENTER button.

To enter a digit, press the SHIFT button and then the desired digit button (1-9).

When "0" is desired, use the O button instead of the 0 button.

When a space is desired, press the button.

To correct a character, press **←** or **→** button to move the cursor to the character to be corrected and then input the new character.

5. To sequentially enter a disc title for the next disc tray, press the NEXT button and perform step 4.

Notes

● Whenever you input a digit in a disc-title, press the SHIFT button. After the digit is input, the **[S]** indicator goes out and the digit buttons change to the alphabet buttons.

● If the ENTER button is not pressed within 1 minute after the magazine symbol, disc tray number or disc title is specified, the displayed contents are canceled and the whole display goes out. To return to title input mode, press the TITLE IN button again.

To check the stored contents

Each time the BEFORE or NEXT button is pressed, the stored contents are displayed in sequence.

To correct a disc title

Press the BEFORE or NEXT button so that the disc title to be corrected appears on the display. Move the cursor to the character to be corrected with the **←** or **→** button and then input the new character. After correcting the disc-title, be sure to press the ENTER button.

To delete a disc title

Press the BEFORE or NEXT button so that the disc title to be deleted appears on the display and press the CANCEL button (colored orange). The disc title goes out. If necessary, input the new disc title and press the ENTER button.

To exit title input mode


Press the TITLE IN button again. The whole display goes out and the title input mode is canceled.

DISK TITLE MEMORY BANK**DISC SEARCH**

You can search for a disc address by specifying the disc title.

1. Press the DISC SEARCH button.

The unit enters disc address search mode and the DISC SEARCH indicator lights in the display.



The cursor of the first character blinks.

2. Specify one or more letters of the disc title (as many letters as required, starting from the first letter) and press the ENTER button.

It is not necessary to input the entire disc title. The unit searches for a disc title which has the same first character starting from disc tray number 1 in magazine A.

- To enter a digit, press the SHIFT button and then the desired digit button (1-9).
- When a space is desired, press the button.

3. If the displayed title is not the one you are looking for, press the BEFORE or NEXT button until the desired title appears in the display.

Notes

- If no disc title with the specified character exists in the memory, "MAG -- DISC --" blinks on the display.
- If only one disc title with the specified character exists, the display blinks once when the NEXT or BEFORE button is pressed.
- If the ENTER button is not pressed within 1 minute after the character is specified, the disc address search mode is canceled and the whole display goes out. To return to disc address search mode, press the DISC SEARCH button again.

To cancel the specified character and search for new one
Press the CANCEL button (colored orange). " _ TITLE" appears in the display and a new character can be input.

To exit disc address search mode


Press the DISC SEARCH button again. The whole display goes out and disc address search mode is canceled.

TITLE SEARCH


You can check the disc title of a certain location by specifying the magazine symbol and disc tray number.

1. Press the TITLE SEARCH button.

The unit enters disc title search mode and the TITLE SEARCH indicator lights in the display.



2. Specify the magazine symbol (A - Z) with the alphabet buttons and press the ENTER button.



3. Specify the disc tray number (1 - 6) with the DISC button and press the ENTER button.

The corresponding disc title is displayed.

4 To check the disc title located before the currently displayed disc title, press the BEFORE button. To check the disc title located after the currently displayed disc title, press the NEXT button.

Notes

- If the specified disc tray has no disc title, the title display shows "-----".
- If the ENTER button is not pressed within 1 minute after the magazine symbol or disc tray number is specified, the displayed contents are canceled and the whole display goes out. To return to the disc title search mode, press the TITLE SEARCH button again.

To exit disc title search mode

Press the TITLE SEARCH button again. The whole display goes out and disc title search mode is canceled.

To enter title input mode

If you want to correct or input a disc title while checking, press the TITLE IN button to enter title input mode. The TITLE INPUT indicator lights, the cursor blinks on the first character of the disc title and you can input a new character.

APPENDIX

Compu link remote control system

The Compu Link Remote Control System controls relative operations between components automatically and facilitates various operations.



This is a system originated and developed by JVC for facilitating various system operations. There are two versions of this system; version 1 and 3. (For version 1 components, "COMPU LINK-1 SYN-CHRO" is marked on the rear panel. For version 3 components, "COMPU LINK-3 SYNCHRO" is marked on the rear panel. This unit belongs to version 3.) The version 3 system controls relative functions between this unit and an amplifier or receiver, in addition to all of the functions of version 1.

The following is a brief explanation of this system:

Automatic source selection

When the remote cable provided is utilized to connect this unit to others equipped with COMPU LINK jacks, switching-in of each system component can be performed with a single touch of the source selector button located on a JVC amplifier or receiver.

When selection is carried out in this manner, the corresponding unit will automatically start operation.

Upon pressing the play button, the source selector for the amplifier or receiver changes automatically. When a new unit is switched in, the previously selected component stops operation within five seconds.

Synchronized recording

Synchronized recording refers to the process in which a JVC cassette deck starts recording, synchronized with this unit. Synchronized recording is carried out as follows:

1. Set the cassette deck to the REC/PAUSE mode in accordance with its instructions.
2. To record only certain tracks, program the tracks in any order, as desired.
3. Press the PLAY ▶/PAUSE button of this unit. The cassette deck automatically starts recording, synchronized with this unit.

Notes

- Synchronized recording stops automatically when this unit stops playback.
- To cancel synchronized recording, press the stop button of this unit or the cassette deck.
- If the REC/PAUSE mode is set on the cassette deck by pressing the PAUSE II button after pressing the REC ● and PLAY ▶ buttons simultaneously, synchronized recording is not possible. For details, refer to the instructions for the cassette deck.

Automatic power on/off function

This function is possible when this unit is connected to an amplifier or receiver of version 3.

This function is to control the power on/off of the receiver or amplifier or this unit respectively as the followings.

- When this unit enters playback mode, the power of the receiver or amplifier is turned on.
- When a magazine is inserted in this unit, the power of the receiver or amplifier is turned on.
- When the source selector of the receiver or amplifier is set to CD function mode, the power of this unit is turned on.

Cautions


- Abnormal operation will result if the power supply of the component(s) is interrupted. If this happens, you must start over again.
- Ensure that the COMPU LINK jacks of the individual components are connected with the provided remote cables. Also be sure to fully read the instructions for each component.

APPENDIX

Care of discs and magazines

How to handle CDs


When handling compact discs, do not touch the surface of the disc (reflective silver side - the side without the label).



Since compact discs are made of plastic, they are easily damaged. If the disc gets dirty, dusty, scratched or warped, the sound will not be picked up correctly and, in addition, such discs may cause the CD player to malfunction.


Even on label side

Do not damage the label side, stick paper to or use any adhesive on this surface.



Maintenance of discs

- When there are fingerprints or other dirt adhering to a disc, wipe the disc with a soft, dry cloth with a movement going from the inside outwards.




- If difficult to clean, wipe the disc with a cloth moistened with water.
- Never use record cleaners, petrol, alcohol or any anti-static agents.

Recommendations for handling the magazine

- Always keep the magazine loaded with its six disc trays.
- Do not expose it to high temperatures or to direct sunlight.
- Do not dismantle the magazine.
- Take care not to drop or hit the magazine. Do not apply any pressure to the disc trays, particularly when removed from the magazine.
- Never apply solvents such as petrol, thinner or insecticide to the surfaces of the magazine or the disc trays. Such solvents may damage their surfaces.

Storage

Make sure that discs are kept in their cases. If discs are piled one on top of another without their protective cases, they can be damaged. Do not put discs in any location where they can be exposed to direct sunlight - or in any place where humidity or temperature is high. Avoid leaving discs in your car!



SPECIFICATIONS

General

System:	Compact disc digital audio system
Signal detection system:	Non-contact optical detection system
CD capacity:	7 discs (one disc in single disc tray and 6 discs in the magazine)
Power requirements:	U.S.A. AC 120 V ~ , 60Hz Australia, U.K. AC 240 V ~ , 50Hz
Power consumption:	18 watts
Dimensions (W x H x D):	435 x 128 x 327 mm 17-3/16 x 5-1/16 x 12-7/8 inches
Weight:	5.0 kg 11.1 lbs

Audio performance

Frequency response:	2 Hz to 20,000 Hz
Dynamic range:	More than 99 dB at 1 kHz
Signal to noise ratio:	More than 107 dB
Channel separation:	More than 94 dB at 1 kHz
Total harmonic distortion:	Less than 0.002% at 1 kHz
Wow and flutter:	Below the measurable limit
Analog output level:	2.0 Vrms at full-scale
Digital output level:	-21 dBm to -15 dBm (Peak)

Accessories

Magazine1
Remote control unit (RM-SX509U)1
Battery (R6P, AA)2
Remote cable1
Audio cord1
Magazine label sheet1

Design and specifications subject to change without notice.

TROUBLESHOOTING

What appears to be a malfunction may not always be serious. Please go through the following list before requesting service.

Symptom	Possible cause	Remedy
The magazine is not expelled when the EJECT ▲ button is pressed.	Power plug is disconnected from the AC outlet.	Connect the plug to an AC outlet.
No sound.	Incorrect output connections.	Connect properly.
Programming is not possible.	The appropriate program indicator does not lights.	Select the program or delete program mode with the PLAY MODE button. In edit mode, select the intro edit or program edit with the EDITING button.
The sound is intermittent and is harsh to the ear.	Disc is dirty.	Wipe off the disc surface with a soft cloth.
	Disc is scratched.	Replace the disc with a new one.
	Disc is warped.	Replace the disc with a new one.
A track on a CD is not played.	A CD is missing.	Load a CD.
	A CD is loaded upside-down.	Load the CD with its label-side up on the disc tray or in the magazine.

Description of Major LSIs

MN171602JHC (IC201) : CD SYSTEM CONTROLLER

1. Terminal Layout

VDD	1		64	OSC1
KEY I0	2		63	OSC2
KEY I1	3		62	Vss
KEY I2	4		61	
KEY I3	5		60	
10G(KEY O8)	6		59	<u>LOAD SW</u>
9G	7		58	<u>R&M SW</u>
8G(KEY O7)	8		57	<u>OPEN SW</u>
7G(KEY O6)	9		56	<u>CLOSE SW</u>
6G(KEY O5)	10		55	<u>SD</u>
5G(KEY O4)	11		54	<u>POWER ON</u>
4G(KEY O3)	12		53	<u>DCS IN</u>
3G(KEY O2)	13		52	<u>DCS OUT</u>
3G(KEY O1)	14		51	<u>OPEN/LOAD</u>
1G(KEY O0)	15		50	<u>CLOSE/UNLOAD</u>
DATA	16		49	<u>DOWN</u>
CLOK	17		48	<u>UP</u>
-VDISP	18		47	<u>UP/DOWN SW</u>
S12	19		46	JAB SW
S11	20		45	<u>SCOR</u>
S10	21		44	<u>RM IN</u>
S9	22		43	RESET
S8	23		42	LOCK
S7	24		41	FOK
S6	25		40	L.ON
S5	26		39	XLAT
S4	27		38	<u>DEFECT SW</u>
S3	28		37	<u>SQSO</u>
S2	29		36	<u>SQCK</u>
S1	30		35	<u>LSI RESET</u>
509/309	31		34	<u>TEST</u>
SENS	32		33	MAG IN

MN171602JHC

Top View

2. Key Matrix

	KEY IN 0	KEY IN 1	KEY IN 2	KEY IN 3
KEY OUT 0	1	2	3	4
KEY OUT 1	5	6	7	8
KEY OUT 2	9	10	+ 10	
KEY OUT 3	DISC 9	DISC 1	DISC 2	DISC 3
KEY OUT 4	DISC 4	DISC 5	DISC 6	OPEN/CLOSE
KEY OUT 5	◀▶	▶▶	■ / CANCEL	▶ II
KEY OUT 6	EJECT	EDIT	SIDE A / B	MEMORY
KEY OUT 7	CALL	P.MODE		

3. Pin Functions Description

Pin NO.	symbol	I/O	Function	Pin NO.	symbol	I/O	Function
1	VDD	I	Power supply	33	MAG-IN	I	Magazine in signal
2	KEY I0	I	Key matrix input	34	TEST	I	Entering test mode with "L"
3	KEY I1	I	Key matrix input	35	LSI RESET	I	Reset signal input
4	KEY I2	I	Key matrix input	36	SQCK	O	Clock output for data transfers
5	KEY I3	I	Key matrix input	37	SQSO	O	80-bit sub Q and 16-bit PCM leveldata
6	10G(KEY O8)	O	FL grid control output (Key matrix output)	38	DEFECT SW	O	Signal that goes "H" during focus searches
7	9G	O	FL grid control output	39	XLAT	O	Latch signal for serial data transfer
8	8G(KEY O7)	O	FL grid control output (Key matrix output)	40	L.ON	O	Turns on laser
9	7G(KEY O6)	O	FL grid control output (Key matrix output)	41	FOK	I	Focus OK signal input
10	6G(KEY O5)	O	FL grid control output (Key matrix output)	42	LOCK	I	Lock signal input
11	5G(KEY O4)	O	FL grid control output (Key matrix output)	43	RESET	I	Reset signal input
12	4G(KEY O3)	O	FL grid control output (Key matrix output)	44	RM IN	I	Remote control signal input.
13	3G(KEY O2)	O	FL grid control output (Key matrix output)	45	SCOR	O	Turns "H" when detecting sub code sync
14	2G(KEY O1)	O	FL grid control output (Key matrix output)	46	JAB SW	I	JAB switch signal
15	1G(KEY O0)	O	FL grid control output (Key matrix output)	47	UP/DOWN SW	I	Height detection signal
16	DATA	O	Serial data output	48	UP	O	Lifter driving control signal
17	CLOK	O	Clock Sigal output	49	DOWN	O	Lifter driving control signal
18	-VDISP	I	FL power supply	50	CLOSE/UNLOAD	O	P1 CLOSE or UNLOAD driving control signal.
19	S12	O	FL segment control output	51	OPEN/LOAD	O	P1 OPEN or LOAD.
20	S11	O	FL segment control output	52	DCS OUT	O	Compulink signal output
21	S10	O	FL segment control output	53	DCS IN	I	Compulink signal input
22	S9	O	FL segment control output	54	POWER ON	O	H:power off, L:power on.
23	S8	O	FL segment control output	55	SD	O	LOAD drive speed Down output.
24	S7	O	FL segment control output	56	CLOSE SW	I	"L" with tray closed
25	S6	O	FL segment control output	57	OPEN SW	I	"L" with tray opened
26	S5	O	FL segment control output	58	R&M SW	I	Reset&Memory SW input.
27	S4	O	FL segment control output	59	LOAD SW	I	Disc load detect signal
28	S3	O	FL segment control output	60		-	Connect to GND
29	S2	O	FL segment control output	61		-	Non connect
30	S1	O	FL segment control output	62	Vss	-	GND
31	509/309	I	Chip select input (H:508/509,L:309)	63	osc2	O	Clock oscillation output
32	SENS	I	Sense Sigal input	64	osc1	I	Clock oscillation input


■ CDX2500BQ(IC401) : DIGITAL SIGNAL PROCESSOR

1. Outline


The CDX2500BQ is a digital signal processing LSI designed for use in compact disc players. It has the following functions:

- All digital signals for regeneration are processed using one chip.
- The built-in RAM enables high-integration mounting.
- Generation by the use of a digital PLL of bit clock pulses for strobing the EFM signal.
- EFM data demodulation
- Subcode demodulation and subcode Q data error detection
- Digital spindle servo system (incorporating an oversampling filter)

2. Terminal Layout



3. Block Diagram



Notes:

- The data at the 64-bit slot is output in 2's complements on an LSB-first basis. The data at the 48-bit slot is output in 2's complements on an MSB-first basis.
- GTOP monitors the state of Frame Sync protection. ("H" : Sync protection window released)
- XUFG is a negative Frame Sync pulse obtained from the EFM signal before Frame Sync protection is effected.
- XPLCK is an inversion of the EFM PLL clock. The PLL is designed so that the falling edge of XPLCK coincides with a change point of the EFM signal.
- The GFS signal turns "H" upon coincidence between Frame Sync and the timing of interpolation protection.
- RFCK is a signal generated at 136- μ s periods using a crystal oscillator.
- C2PO is a signal to indicate a data error.
- XRAOF is a signal issued when a jitter margin of $\pm 28F$ is exceeded by the 32K RAM.

4. Pin Description

Pin No.	Symbol	I/O	Description
1	FOK	I	Focus OK input pin. Used for SENS output and servo auto sequencer.
2	FNW	O	Non connection
3	MON	O	Output for spindle motor ON / OFF control.
4	MDP	O	Output for spindle servo control.
5	MDS	O	Output for spindle servo control (Non connection).
6	LOCK	O	This terminal is "H" when the GFS signal sampled at 460Hz is "H". It turns "L" when the GFS signal turns out "L" 8 or more times in succession.
7~9	—	--	Non connection
10	TEST	I	Test pin (Normally at 0V)
11	PDO	O	Output of charge pump for analog EFM PLL (Non connection).
12	Vss	--	GND
13~16	—	--	Non connection
17	VCKI	O	Clock input from external VCO for vari-pitch control. $f_c = 16.9344\text{MHz}$.
18	FILO	O	Output of filter for masterPLL (Slave = Digital PLL)
19	FILI	I	Input to filter for master PLL.
20	PCO	O	Output of charge pump for master PLL.
21	AVss		Analog GND
22	CLTV	I	VCO control voltage input for master PLL.
23	AV _{DD}	--	Analog power supply
24	RF	I	EFM signal input
25	TEST2	I	TEST pin (Connected to GND)
26	TEST3	I	TEST pin (Connected to GND)
27	ASYO	O	EFM full-swing output
28	TEST4	I	TEST pin (Connected to GND)
29	NC	--	Non connection
30	PSSL	I	Input used to switch the audio data output mode. "L" for serial output, "H" for parallel output.
31	WDCK	O	D / A interface for 48-bit slot. Word clock $f = 2Fs$.
32	LRCK	O	D / A interface for 48-bit slot. LR clock $f = Fs$.
33	V _{DD}	--	Power supply
34	DA16	O	Output DA16(MSB) when PSSL = 1 or serial data from 48-bit slot(2's completements,MSB first) when PSSL = 0.
35	DDA15	O	Output DA15 when PSSL = 1 or bit clock from 48-bit slot when PSSL = 0.
36~51	—	--	Non connection
52	VSS	--	GND
53	XTAI	I	Input to 16.9344MHz Xtal oscillation circuit or 33.8688MHz input.
54	XTAO	O	Output of 16.9344 MHz Xtal oscillation circuit.
55	XTSL	I	Xtal selection input pin. "L" for 16,344MHz Xtal, "H" for 33.8688 MHz Xtal.
56~58			Non connection
59	MD2	I	Digital-Out ON/OFF control. "H" for ON, "L" for OFF.
60	DOUT	O	Digital-Out output pin.
61,62	—	--	Non connection
63	SCOR	O	Turns "H" when subcode Sync S0 or S1 is detected.
64	SBSO	O	Serial output of Sub P to W.
65	EXCK	I	Clock input for reading SBSO.
66	SQSO	O	Outputs 80-bit Sub Q and 16-bit PCM peak-level data.
67	SQCK	I	Clock input for reading SQSO.
68	MUTE	I	"H" for muting, "L" for release.
69	SENS	--	SENS output to CPU.
70	XRST	I	System reset. "L" for resetting.
71	DATA	I	Inputs serial data from CPU.
72	XLAT	I	Latches serial data input from CPU at falling edge.
73	V _{DD}	--	Power supply(+ 5V)
74	CLOK	I	Inputs serial data transfer clock from CPU.
75	SEIN	I	Inputs SENSE from SSP.
76	CNIN	I	Inputs track jump count signal.
77	DATO	O	Outputs serial data to SSP.
78	XLYTO	O	Latches serial data output to SSP at falling edge.
79	CLKO	O	Outputs serial data transfer clock to SSP.
80	MIRR	I	Inputs mirror signal to be used by auto sequencer when jumping 128 or more tracks.

■ CXA1372S (IC601) : RF SIGNAL PROCESSING SERVO AMPLIFIER

1. Outline

The CXA1372S is a bipolar IC developed for RF signal processing (focus OK, mirror, defect detection, EFM comparator) and servo control.


2. Functions

- Auto asymmetry control
- Focus OK detection circuit
- Mirror detection circuit
- Defects detection, counter measures circuit
- EFM comparator
- Focus servo control
- Tracking servo control
- Sled servo control

3. Terminal Layout

TE	1	48	TZC
TDFTC	2	47	DVEE
ATSC	3	46	RFO
FZC	4	45	RFI
FE	5	44	CP
FDFTC	6	43	CB
VC	7	42	DVCC
FGD	8	41	CC2
FS3	9	40	CC1
FLB	10	39	FOK
FE0	11	38	EFM
FE-	12	37	ASY
SRCH	13	36	DFCT
TGU	14	35	MIRR
TG2	15	34	DGND
AVCC	16	33	SENS
TAO	17	32	C.OUT
TA-	18	31	XRST
SL +	19	30	DATA
SLO	20	29	XLT
SL -	21	28	CLK
FSET	22	27	LOCK
ISET	23	26	DIRC
SSTOP	24	25	AVEE

4. Internal Block Diagram



5.Pin Description


Pin No	Symbol	I/O	Description
1	TE	I	Input pin of tracking error amplifier.
2	TDFCT	I	Capacitor connecting pin for time constant during defects.
3	ATSC	I	Window comparator input pin for ATSC detection.
4	FZC	I	Pin for focus zero-cross comparator input.
5	FE	I	Input pin of focus error.
6	FDFCT	I	Capacitor connecting pin for time constant during defect functions.
7	VC	I	Center voltage input pin. For dual power: GND For single power supply: (VCC + GND)/2
8	FGD	I	Connect a capacitor between this pin and pin3 to reduce high-frequency gain.
9	FS3	I	The high-frequency gain of the focus servo is switched through FS3 ON and OFF.
10	FLB	I	Time constant external pin to raise the low bandwidth of the focus servo.
11	FE0	O	Focus drive output.
12	FE-	I	Inverse input for focus amplifier.
13	SRCH	I	Time constant external pin for formation of focus search waveform.
14	TGU	I	Time constant external pin for the selection of tracking high band gain.
15	TG2	I	Time constant external pin for the selection of tracking high band gain.
16	AVCC	--	Power supply
17	TAO	O	Tracking drive output.
18	TA-	I	Inverse input pin for tracking amplifier.
19	SL +	I	Non-inverse input pin for sled amplifier.
20	SLO	O	Sled drive output.
21	SL-	I	Inverse input pin for sled amplifier.
22	FSET	I	Pin to set peak frequency of focus tracking phase compensation and fo of CLV LPF.
23	ISET	I	Current is input to determine focus search, track jump, and sled kick height.
24	SSTOP	I	Limit SW ON/OFF signal detection pin for disc inner periphery detection.
25	AVEE	--	-5V
26	DIRC	I	Pin for one-track jump. Contains 47kΩ pull-up resistor.
27	LOCK	I	At "L" sled runaway prevention circuit operate. Contains a 47kΩ pull-up resistor.
28	CLK	I	Serial data transfer clock input from CPU.
29	XLT	I	Latch input from CPU.
30	DATA	I	Serial data input from CPU.
31	XRST	I	Reset input pin, reset at "L".
32	C.OUT	O	Track number count signal output.
33	SENS	O	Outputs FZC, AS, TZC and SSTOP through command from CPU.
34	DGND	--	GND
35	MIRR	O	MIRR comparator output pin.
36	DFCT	O	Output pin of DEFECT comparator.
37	ASY	I	Input pin of auto asymmetry control.
38	EFM	O	Output pin of EFM comparator.
39	FOK	O	Output pin of FOK comparator.
40	CC1	I	Output pin of DEFECT bottom hold.
41	CC2	O	Input pin for the capacitance coupled output of DEFECT bottom hold.
42	DVCC	--	-5V
43	CB	I	Connection pin of DEFECT bottom hold capacitor.
44	CP	I	Connecting pin of MIRR hold condenser. Non-inverted input pin of MIRR comparator.
45	RFI	I	Input pin with coupling capacitor where RF summing amplifier output is connected.
46	RFO	O	Output pin of RF summing amplifier and check point of eye pattern.
47	DVEE	--	-5V
48	TZC	I	Input pin of tracking zero-cross comparator.

■ MN35500(IC301) : D/A CONVERTER

1. Terminal Layout

DIN	1	28 RSBDN
LRCK	2	27 RSBUP
BCK	3	26 M3
M4	4	25 DVDD1
DVDD2	5	24 XIN
CKO	6	23 XOUT
DVSS2	7	22 DVSS1
M1	8	21 M2
OUT1C	9	20 OUT2C
OUT1B	10	19 OUT2B
AVDD1	11	18 AVDD2
OUT1D	12	17 OUT2D
OUT1A	13	16 OUT2A
AVSS1	14	15 AVSS2

2. Block Diagram



3. Description


Pin No	Symbol	I/O	Description	Pin No	Symbol	I/O	Description
1	DIN	I	Data input	15	AVSS2	--	Analog ground 2
2	LRCK	I	LR clock input	16	OUT2A	O	2A PEM output
3	BCK	I	Bit clock input pin	17	OUT2D	O	2D PEM output
4	M4	--	Operational mode control 4	18	AVDD2	--	Analog power supply 2
5	DVDD2	--	Digital power supply 2	19	OUT2B	O	2B PEM output
6	CKO	I	Clock output	20	OUT2C	O	2C PEM output
7	DVSS2	--	Digital ground 2	21	M2	--	Operational mode control 2
8	M1	--	Operational mode control 1	22	DVSS1	--	Digital ground pin 1
9	OUT1C	O	1C PEM output	23	XOUT	O	Crystal oscillator output
10	OUT1B	O	1B PEM output	24	XIN	I	Crystal oscillator input
11	AVDD1	--	Analog power supply 1	25	DVDD1	--	Digital power supply 1
12	OUT1D	O	1D PEM output	26	M3	--	Operational mode control 3
13	OUT1A	O	1A PEM output	27	RSBUP		
14	AVSS1	--	Analog ground 1	28	RSBDN		

■ CXA1571S(IC501) : RF AMP FOR COMPACT DISC

1. Outline

The CXA1571S IC for compact disc #‐point method optical pickup output has following functions.
 •RF amplifier • Focus error amp • Tracking error • APC circuit

2. Internal Block Diagram




3. Pin Description


Pin No.	Symbol	I/O	Description
2	LD	O	APCamp output pin.
3	PD	I	APCamp input pin.
4	PD1	I	RF I-V amp inverted input pins; they are connected to the A + C and B + D pins of the photodiode and receive current input.
5	PD2	I	
7	F-IN	I	F and E I-V amp inverted input pin; they are connected to Photodiodes F and E and receive current input.
8	E-IN	I	
9	VR	O	(VCC + VEE) / 2 DC voltage output pin.
10	VC	I	VC intermediate voltage input pin; when dual $\pm 5V$ power supplies are used, this pin is connected to GND; for a single $+5V$ power supply, it is connected to the VR pin.
13	EO	O	Monitor output pin for I-V amp E.
14	EI	I	Gain adjustment pin for I-V amp E.
15	TE	O	Tracking error amp output pin.
16	FE-BIAS	I	Bias adjustment pin for the mon-inverted side of the focus error amp.
17	FE	O	Focus error amp output pin.
18	RFO	O	RF amp output pin.
19	RF1	I	RF inverted side input pin; the resister connected between this pin and the RFO pin determines the gain of the RF amp.
20	LD-ON	I	This pin switches the APCamp on / off: on for VCC, off for ground.

Internal Block Diagram of Other ICs


■ VC4580D (IC303,304,251) : Dual OP Amp.



■ M5218AL (IC802,871) : Dual OP Amp.




■ GP1U571X (IC203) : Receiver for remote controller



■ MN1281 (IC202) : Reset IC

Block Diagram




Pin No.	Pin Name	Functions
1	V _{DD}	Power supply
2	V _{SS}	Ground
3	OUT	Reset signal output : Low level is output when resetting : High level is output when cancelling the reset.

Internal Connections of FL Display Tube

■ ELU0001-132 (FL201)

1. Grid Layout



2. Pin Connections

Terminal No	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
ELECTRODE	F1	F1	F1	NP	10G	9G	8G	7G	6G	5G	4G	3G	2G	1G	NC	NC	P(S12)	P(S11)
Terminal No	19	20	21	22	23	24	25	26	27	28	29	30	31	32				
ELECTRODE	P(S10)	P(S9)	P(S8)	P(S7)	P(S6)	P(S5)	P(S4)	P(S3)	P(S2)	P(S1)	NP	F2	F2	F2				

Notes F: Filament
 G: Grid
 P: Anode

NP: No Pin
NC: No Connection

3. Anode Connection Table

	10G	9G	8G	7G	6G	5G	4G	3G	2G	1G
S1	6	—	—	—	—	—	—	—	—	—
S2	5	CONTINUE	TRACK	—	STEP	—	EACH	○ ○	REMAIN	—
S3	4	PROGRAM	a	a	a	a	a	a	a	a
S4	3	RANDOM	b	b	b	b	b	b	b	b
S5	2	DEL.PRG	c	c	c	c	c	c	c	c
S6	1	DDR	d	d	d	d	d	d	d	d
S7	(6)	AUTO CLOSE	e	e	e	e	e	e	e	e
S8	(5)	P	f	f	f	f	f	f	f	f
S9	(4)	(P)	g	g	g	g	g	g	g	g
S10	(3)	1	▶	4	REPEAT	7	PRGM EDIT	10	SIDE-A	13
S11	(2)	2		5	1	8	INTRO	11	SIDE-B	14
S12	(1)	3	—	6	DISC	9	EDIT	12	—	15

Disassembly Procedures

1. Removing the top cover

- 1) Remove the 4 screws fastening both sides of the Top Cover, and the 2 screws fastening the rear sides.
- 2) Remove the Top Cover.

2. Removing the front panel

- 1) Remove the screw Ⓐ
- 2) Remove the 2 screws fastening both sides of the Front Panel, and the 3 screws fastening bottom of the Front Panel.
- 3) Disconnect the connector. (J201)
- 4) Remove the Front Panel.




Fig.1

3. Removing the changer assembly

- 1) Remove the top cover.
- 2) Remove the front panel.
- 3) Remove the 2 screws Ⓐ fastening the changer assembly.
- 4) Disconnect the connectors. (ⒶⒷⒸⒹ)
- 5) Slide the changer assembly to arrow direction ①.
- 6) Remove the changer assembly.
* NOTICE (for reinstalling)
Wire ④ should be set as Fig.2.

4. Removing the turntable base (Fig.2)

- 1) Remove the changer assembly.
- 2) Turn over the changer assembly.
- 3) Remove the 3 screws ①.
* NOTICE : The left side spring differs from the right side ones.
- 4) Take the turntable base out.




Fig.2

5. Exchanging the pickup (Fig.2)

- 1) Remove the screw ①, and remove the feed nut support.
- 2) Remove the screw ②.
- 3) Remove the Feed Screw assembly , and remove the Pickup with the pickup shaft .
- 4) Exchange the pickup.

6. Removing the magazine holder (Fig.3)

- 1) Remove the 2 screws fastening the magazine holder.
- 2) Slide the magazine holder to arrow direction ①.
- 3) Remove the magazine holder to upside , and remove the tray stopper at the same time.




Fig.3

7. Removing the LIFTER UNIT Ass'y (Fig.3)

- 1) Remove the MAGAZINE HOLDER.
- 2) Lift the LIFTER UNIT Ass'y to the top position.
- 3) Remove the ELEVATOR ARMS from the CHASSIS BASE and the LIFTER UNIT Ass'y.
- 4) Remove the LIFTER UNIT Ass'y.

※ The LIFT CAM can be released, After removing the LIFTER UNIT Ass'y (Fig.8)

- 1) When installing the lift cam,
Put the cam slider to the position shown in fig 8.
- 2) Install the changer assembly.
- 3) Set the power ON to operate the mechanism.
- 4) Set the power OFF while the disc is playing.
- 5) Set the power ON again.
In this case the unit will be reseted.




Fig.4

8. Removing the P1 RAIL BASE Ass'y (Fig.6,8)

- 1) Rotate the gear ⑩ clockwise a little.
- 2) Remove the P1 TRAY.
- 3) Remove the screw ⑪.
- 4) Remove the P1 RAIL BASE Ass'y.

9. Removing the P1 RAIL BASE (Fig.6,7,8)

- 1) Remove the P1 RAIL BASE Ass'y.
- 2) Remove the screw ① fixing the open/close sw and the sw.
- 3) Pull the P1 RAIL BASE by pulling up the hook ② slightly.
- 4) Remove the P1 RAIL BASE.

* Install gear ③ so that part ④ shown in fig.7 is perpendicular to the P1 rail base.




Fig.5




Fig.6

The Gear Position when the P1 Rail Base is pulled out forward.




Fig.7





Fig.8


10. Removing the spindle motor

- 1) Remove the TURN TABLE BASE.
- 2) Turn over TURN TABLE BASE.
- 3) Remove the pressed-in turntable.
- 4) Remove the 2 screws fastening the motor.
- 5) Remove the spindle motor.



11. Mounting the spindle motor

- 1) Alternately tighten the 2 screws.
- 2) Fit the turntable by pressing gently at the centre to obtain a distance of $10.3\text{mm} \pm 0.1\text{mm}$ from the mechanism base to the top of the turntable.



Adjustment Procedures

1. FE Bias

- 1) Connect an oscilloscope to TP 6(FE) and TP 3(GND).
- 2) Adjust R512(FE bias) so that the DC voltage becomes $0 \pm 10\text{mV}$.

2. EF balance


- 1) Connect an oscilloscope to TP 4(TE) and TP 3(GND).
- 2) Play a disc.
- 3) Short-circuit between TP 1(TEST) and TP 3(GND).
- 4) Adjust R513(EF balance) so that the center of the waveform at TP4(TE) becomes 0V.

3. Focus gain

- 1) Connect an oscilloscope to TP 6(FE) and TP 3(GND).
- 2) Play a disc.
- 3) Adjust R603(F.GAIN ADJ.) so that the waveform becomes below figure 1.

4. Tracking gain

- 1) Connect an oscilloscope to TP 4(TE) and TP 3(GND).
- 2) Play a disc.
- 3) Short circuit TP5(TEIN) to TP3(GND).
- 3) Adjust R604(T.GAIN ADJ.) so that the waveform becomes below figure 2.



Focus Gain Adjustment




Figure. 1

Tracking Gain Adjustment




Figure. 2

Note :

If the gain is out of adjustment, the symptoms below will appear.

● Gain too low

- Focus gain : Focus is not obtained and disc does not rotate.
Tracking gain : Mechanical shock occurs easily and sound is interrupted. Or time counter display stop counting.

● Gain too high

- Focus gain : Scratches (on the disc) easily interrupt play, and noise is increased during play.
Tracking gain : Since the follow-up ability of the pickup is too high, the pickup may oscillate and oscillating sound may output.

As described above, the focus and tracking gain adjustment are performed so as to satisfy mutually contradictory characteristics. A simplified adjustment procedure is described below. However, since exact adjustment can not be performed prior to adjustments,

note(or mark) the positions of the semi-fixed VRs.

If the positions after the simplified adjustment are only different, return the VRs to their original position.


Maintenance of Laser Pickup

(1) Life of the laser diode

When the life of the laser diode has expired, the following symptoms will appear.

1. The level of RF output (EFM output: amplitude of eye pattern) will be low.
2. The drive current required by the laser diode will be increased.


In such a case, check the life of the laser diode following the flowchart below



(2) Measurement of laser diode drive current

Replace the jump wire (W199) shown below with the resistor (1Ω).

Measure the voltage across the resistor with a milli-voltmeter. When the voltage is more than 120mV, it shows that the life of the laser diode has expired



(3) Semi-fixed resistor on the APC PC board

The semi-fixed resistor on the APC printed circuit board which is attached to the pickup is used to adjust the laser power. Since this adjustment should be performed to match the characteristics of the whole optical block, do not touch the semi-fixed resistor.

If the laser power is lower than the specified value, the laser diode is almost worn out, and the laser pickup should be replaced.

If the semi-fixed resistor is adjusted while the pickup is functioning normally, the laser pickup may be damaged due to excessive current.

Replacement of Laser Pickup

Turn off the power switch and, disconnect the power cord from the AC outlet.

Replace the pickup with a normal one. (Refer to "Laser pickup Removal" on the previous page)

Plug in the power cord, and turn the power switch on. At this time, check that the laser emits for about 3 seconds and the objective lens moves up and down.
Note: Do not observe the laser beam directly.

Play a disc, and when it starts rotating, short circuit between TP1 (TEST) and TP3 (GND).

Adjust focus gain.

Adjust tracking gain.



Disconnect TP1 (TEST) from TP3 (GND).


Check the eye-pattern at the TP2 (RF).


Finish.

Note: Since one adjustment may affect other settings, repeat these adjustments a few times.

Initial Operation of Mechanism







(note) XL-M309TN/ XL-M408BK/XL-M409TN takes 100ms to shift from vertical action to horizontal action and vice versa.

Operation check by each switch.

SW801 : Single tray open / close detect switch.

When a single tray is ejected, the open signal is "L" and when it is closed, the close signal is "L"

SW802 : Magazine in switch.

When a magazine is inserted, the switch is turned on.

SW803 : JAB switch.

When drive plate comes toward, the switch is turned on. (The switch is turned on momentarily.)

SW803 : Tray load switch.

When the tray of a disc is loaded, the switch is turned on.

SW804 : UP/DOWN switch.

When the mechanism goes up or down, this sw turns on and off alternately.

SW805 : Reset switch.


When the mechanism comes to the point under the initial position, the switch is turned on.

SW805 : Memory switch.




When the power is off in playing a disc, and on again, the switch detect which height the tray should be returned.

SW807 : Pickup rest switch.

When pickup comes to the initial position, the switch is turned on.




Flow of Functional Operation Until TOC is Read




Troubleshooting


The following flowchart shows each circuit's condition about from "power on" until "ready to play".




Front Section




Focus section




Tracking section



Feed section



Spindle section



XL-M508BK
XL-M509TN



XL-M508BK
XL-M509TN

XL-M508BK
XL-M509TN




VICTOR COMPANY OF JAPAN, LIMITED
AUDIO DIVISION, 1644, SHIMOTURUMA, YAMATO-SHI, KANAGAWA-KEN, 242, JAPAN

(No.20379)

JVC
Printe
9212 (

Block Diagram

XL-M508BK
XL-M509TN




Printed Circuit Boards

XL-M509TN

XL-M509TN

■Main&Front P.C.Board(ENN-354)




Schematic Diagrams

(1) Main Section

How to Use Schematic Diagrams

1. indicates the +B line.
 2. indicates the -B line.
 3. indicates signal path.
 4. Parts marked with and those in the shaded area are parts for safety.
Be sure to use one with the specified part number.
 5. This is the standard circuit diagram. The circuits and circuit constants are subject to change for improvement without notice.




ograms


How to Use Schematic Diagrams

1. — indicates the +B line.
 2. - - - indicates the -B line.
 3. — indicates signal path.
4. Parts marked with \triangle and those in the shaded area are parts for safety.
- Be sure to use one with the specified part number.
5. This is the standard circuit diagram. The circuits and circuit constants are subject to change for improvement without notice.

D E F G H I J K L M N O P Q R S T


ENN-354-2





(No.20379)

(No.20379)










(No.20379)

(No.20379)








(No.20379)


	J	C, E, EF, G, BS	U, UT
R101, 102	NONE	2.2	2.2
R112	NONE	10 UNF-F (1/4W)	10 UNF-F (1/4W)
CP101	NONE	ICP-N5	ICP-N5
R142	NONE	56 UNF-F (1/4W)	56 UNF-F (1/4W)
C103	2200/16	2200/16	3300/16

(2) Front Section




E F G H I J K L M N O P Q R S T







(No.20379)





(No.20379)








(No.20379)




A, BS, EN, EF, U, UT, G




(No.20379)




A, BS, EN, EF, U, UT, G



C, J



Exploded View of Assemblies and Application points for Grease



G-425A
G-474C
G-331

PARTS LIST

Note : All printed circuit boards and its assemblies are not available as service parts.

Contents

General Exploded View and Parts List	2 - 2
CD Changer Ass'y and Parts List	2 - 5
■ How to install the gears and pulley when servicing.	2-10
Printed Circuit Board Ass'y and Parts List	2-11
■ ENN-354 <input type="checkbox"/> Main & Front PC Board Ass'y	2-11
Accessories List	2-15
Packing Materials and Part Numbers	2-16

General Exploded View and Parts List

■ Parts List

⚠	Item	Part Number	Part Name	Q'ty	Description	Areas
	1	EFP-XLM508BKE (S 1-1 E102653-007 1-2 E308282-002 1-3 E72968-001 2 SDSG3006M	FRONT PANEL ASSY FRONT PANEL WINDOW SCREEN JVC MARK SCREW	1 1 1 1 6		
	3 4 5 6 7	E74179-001 E75896-001 E308284-001 SDSF2608Z EWR135K-42TT	KNOB SPACER HEADPHONE BRACKET SCREW FLAT WIRE ASSY	1 2 1 13 1	FRONT FOOT	
	8 9 10 11 12	E25834-006 SBSG3008M E406308-001 E102650-001 E406472-004	METAL COVER SCREW SPECIAL SCREW CHASSIS BASE FOOT ASSY	1 2 4 1 2	REAR	
	13 14 15 16 17	SBST3008Z E308285-002 --- E406507-001 GB3G3008CC	SCREW FITTING CD CHANGER MECHANISM UNIT ASS'Y CAUTION LABEL SCREW	2 1 1 1 4	REAR SEE PAGE 2-5	
⚠ ⚠ ⚠ ⚠ ⚠	18	ETP1010-51EA ETP1010-51EABS ETP1010-51EA ETP1010-51EA ETP1010-51EA	POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER	1 1 1 1 1		A BS EF EN G
	19 20 - E308453-003 E308453-003 E308453-004F	E65389-004 E207686-004 - E308453-003 E308453-003 E308453-004F	SPECIAL SCREW REAR PANEL RATING LABEL RATING LABEL RATING LABEL	2 1 1 1 1		EN EF G
	21 22 23 24 -	E73273-006 E72018-001 E75217-001 SBST3006Z E61029-005	SPECIAL SCREW WIRE CLAMP WIRE CLAMP SCREW NUMBER LABEL	7 1 1 2 1		
	- - - -	E70891-001 QZL1031-101 E70419-002F E70891-001	LABEL LABEL F.MARK LABEL LABEL	1 1 1 1		EF G G

⚠ SAFETY PARTS

The Marks for Designated Areas

A Australia

EN Scandinavia


EF Continental Europe

G Germany


BS the U.K.

No mark indicates all areas.

■ Exploded View



CD Changer Ass'y and Parts List



■ Parts List (CD Changer Mechanism Ass'y)


Item	Part Number	Part Name	Q'ty	Description	Areas
1	30100101T	CHASSIS BASE	1		
2	30050115T	GUIDE BOSS	2		
3	300501302T	PRINTED CIRCUIT BOARD A ASSY	1		
4	301001301T	PRINTED CIRCUIT BOARD D ASSY	1		
5	300501304T	PRINTED CIRCUIT BOARD P ASSY	1		
6	301002502T	ELEVATOR ARM A ASSY	3		
7	301002503T	ELEVATOR SIDE ARM B ASSY	2		
8	301002504T	ELEVATOR FRONT ARM A ASSY	1		
9	30100221T	CAM LEVER SPRING	1		
10	30100222T	CS COLLAR SCREW	1		
11	30100223T	CAM SPRING	1		
12	30100202T	LIFT CAM	1		
13	301002501T	ELEVATOR MOTOR BRACKET ASSY	1		
14	RF-370C-15370	MOTOR	2		
15	30100210T	ELEVATOR GEAR B	2		
16	30100211T	ELEVATOR GEAR C	1		
17	30100212T	ELEVATOR GEAR D	1		
18	640101204T	LEAF SWITCH	2		
19	30100204T	CAM SLIDER	1		
20	30100205T	CAM SPRING PLATE	1		
21	30100206T	CAM LEVER	1		
22	30100207T	CAM ROLLER	1		
23	30100301T	GUIDE BASE	1		
24	30100311T	ELEVATOR SLIDE LEVER	1		
25	30100312T	ELEVATOR SLIDE LEVER SPRING	1		
26	30100303T	MAGAZINE GUIDE	1		
27	30100304T	MAGAZINE GUIDE	1	LEFT	
28	30100305T	GUIDE COVER	1	RIGHT	
29	30050309T	TRAY STOPPER	1		
30	30100310T	RELEASE LEVER	1		
31	30100308T	ELEVATOR KICK LEVER	1		
32	30100307T	LOCK LEVER	1		
33	30100309T	ELEVATOR KICK LEVER SPRING	1		
34	30100313T	RELEASE LEVER SPRING	1		
35	30100306T	CAM STABILIZER	1		
36	64020403T	PUSH SWITCH	4		
37	30050508T	FEED GEAR A	2		
38	301005501T	FEED RAIL ASSY	1		
39	30100504T	HOOK SLIDE GEAR	1		
40	30100505T	SLIDE GEAR PLATE	1		
41	30050738T	TURNTABLE BASE	1		
42	60020705T	MOTOR	1		
43	30050729T	TURNTABLE	1		
44	30050713T	TURNTABLE PLATE	1		
45	30050742T	CONTROLLER SPRING	1		
46	30050721T	FLOATING RUBBER	3		
47	30050715T	FLOATING SPRING (B)	2		
48	30050743T	FLOATING SCREW	3		
49	30050740T	FLOATING SPRING	1		
50	60021102T	MOTOR	1		
51	30050709T	MOTOR PULLEY	1		
52	30050714T	FEED MOTOR BELT	1		
53	30050737T	PICK UP SUPPORT	1		
54	30050724T	SHAFT HOLDER A	1		
55	300507303T	FEED SCREW ASSY	1		

Item	Part Number	Part Name	Q'ty	Description	Areas
56	30050728T	PICK UP SHAFT	1		
57	30050735T	FEED NUT SUPPORT	1		
58	30050739T	FEED NUT SPRING	1		
59	EWS26A-B921	SOCKET WIRE	1		
60	OPTIMA-5S	PICK UP	1		
61	EWS264-B924	SOCKET WIRE ASSY	1		
62	301008503T	RAIL BASE ASSY	1		
63	30100802T	RAIL	1	LEFT	
64	30100803T	RAIL	1	RIGHT	
65	30100804T	HOOK LEVER	1		
66	301008502T	LP BRACKET ASSY	1		
67	301008301T	MAGAZINE HOLDER ASSY	1		
68	30050114T	CHASSIS SUPPORT	1		
69	30050725T	SHAFT HOLDER B	1		
70	12030105T	TIE BAND	4		
71	300507305T	TURNTABLE BASE ASSY	1		
72	301004502T	PLUS 1 BASE ASSY	1		
73	301004301T	PLUS 1 RAIL BASE ASSY	1		
74	30100415T	STOPPER SPRING	1		
75	30050416T	STOPPER	1		
76	30100411T	PLUS 1 BELT	1		
77	30100403T	PLUS 1 GEAR A	2		
78	30100404T	PLUS 1 GEAR B	1		
79	30100515T	FEED GEAR C	2		
80	30100506T	FEED GEAR D	1		
81	30100516T	FEED GEAR E	3		
82	30100413T	FEED GEAR D SPRING	1		
83	30100412T	FEED GEAR E SPRING	1		
84	30100414T	SWITCH ACTUATOR	1		
85	30100418T	PLUS 1 SLIDE RAIL	1		
86	30101015T	VINYL WIRE	1		
87	E26554-004	TRAY	1		
88	SPSK1722M	SCREW	2		
89	9C0420253T	SCREW	1		
90	9C0720601T	SCREW	2		
91	9C0420303T	SCREW	1		
92	9C0420403T	SCREW	2		
93	9P0420031T	SCREW	4		
94	9P0220031T	SCREW	2		
95	9P0230041T	SCREW	2		
96	9P3320032T	SCREW	1		
97	9P0420051T	SCREW	3		
98	9P0420041T	SCREW	3		
99	9W0250110T	WASHER	14		
100	9W0113080T	WASHER	3		
101	REE3000X	E.RING	3		
102	9W0640040T	WASHER	3		
103	301002301T	ELEVATOR MOTOR ASSY	2		
104	300507306T	FEED MOTOR ASSY	1		
105	301002302T	CAM SLIDER ASSY	1		
106	30051007T	WIRE	1	ORANGE	
107	30051011T	WIRE	2	YELLOW	
108	30051014T	WIRE	1	BLUE	
109	30101001T	WIRE	2		
110	30101002T	WIRE	1	YELLOW	
111	30101003T	WIRE	1	BRACK	


Item	Part Number	Part Name	Q'ty	Description	Areas
112	30101005T	WIRE	1	BRACK	
113	30101006T	WIRE	1	RED	
114	30101007T	WIRE	1		
115	30101008T	WIRE	1		

- How to install the gears and pulley when servicing.


1. Elevator Motor , Loading Motor



2. Loading Motor for single tray




3. Feed Motor



Printed Circuit Board Ass'y and Parts List

■ENN-354 □ Main & Front PC Board Ass'y

Note : ENN-354 □ varies according to the areas employed. See note (1) when placing an order.



Note (1)

PC Board Ass'y	Designated Areas
ENN-354 [A]	Australia
ENN-354 [B] BS	the U.K.
ENN-354 [E]	Scandinavia, Germany Continental Europe

TRANSISTORS

▲ ITEM	PART NUMBER	DESCRIPTION	AREA
Q101	2SB1187(E,F)	SILICON ROHM	
Q102	2SC2060(Q,R)	SILICON ROHM	
Q103	2SD1302(S,T)	SILICON MATSUSHITA	
Q104	2SA933S(R,S)	SILICON ROHM	
Q105	2SB1357(E,F)	SILICON ROHM	
Q106	2SD2144S(VW)	SILICON ROHM	
Q107	2SD2144S(VW)	SILICON ROHM	
Q108	DTA114YS	SILICON ROHM	
Q114	2SA733A(P,Q)	SILICON NEC	
Q131	2SA933S(R,S)	SILICON ROHM	
Q132	2SD2144S(VW)	SILICON ROHM	
Q201	DTA114YS	SILICON ROHM	
Q202	DTC144ES	SILICON ROHM	
Q203	DTC114YS	SILICON ROHM	
Q371	2SD1302(S,T)	SILICON MATSUSHITA	
Q372	2SD1302(S,T)	SILICON MATSUSHITA	
Q601	2SD2037(E,F)	SILICON ROHM	
Q602	2SA934(Q,R)	SILICON ROHM	
Q603	2SD2037(E,F)	SILICON ROHM	
Q604	2SB1357(E,F)	SILICON ROHM	
Q605	DTC144ES	SILICON ROHM	
Q871	2SC2060(Q,R)	SILICON ROHM	
Q872	2SA934(Q,R)	SILICON ROHM	
Q875	DTC144ES	SILICON ROHM	

I. C. S.

▲ ITEM	PART NUMBER	DESCRIPTION	AREA
IC201	MN171602JHC	I.C.	
IC202	MN1281(P,Q)	I.C.	MATSUSHITA
IC203	GP11571X	I.C.	SHARP
IC251	VC4580D	I.C.	DAINICHI
IC301	MN35500	I.C.	
IC303	VC4580D	I.C.	DAINICHI
IC304	VC4580D	I.C.	DAINICHI
IC401	CXD2500BQ	I.C.	
IC501	CXA1571S	I.C.	1680
IC601	CXA1372S	I.C.	1680
IC602	STA341M(A)	I.C.	SANKEN
IC802	M5218AL	I.C.	MITSUBISHI
IC871	M5218AL	I.C.	MITSUBISHI

DIODES

▲ ITEM	PART NUMBER	DESCRIPTION	AREA
D101	S1V820F	SILICON SINDENGEN	
D102	MTZ5.6JB	ZENER ROHM	
D103	MTZ5.6JB	ZENER ROHM	
D113	1SR139-200	SILICON ROHM	
D114	MTZ33JC	ZENER ROHM	
D131	ISS113	SILICON ROHM	
D132	ISS113	SILICON ROHM	
D201	ISS113	SILICON ROHM	
D202	ISS113	SILICON ROHM	
D203	ISS119	SILICON HITACHI	
D204	ISS119	SILICON HITACHI	
D205	ISS119	SILICON HITACHI	
D206	ISS119	SILICON HITACHI	
D207	ISS119	SILICON HITACHI	
D208	ISS119	SILICON HITACHI	
D209	ISS119	SILICON HITACHI	
D210	ISS119	SILICON HITACHI	
D211	ISS119	SILICON HITACHI	
D212	SLH-56VC50F130	L.E.D. ROHM	A
D212	SLA-580LT70F124	L.E.D. ROHM	BBS
D212	SLH-56VC50F130	L.E.D. ROHM	E
D213	ISS113	SILICON ROHM	
D870	ISS113	SILICON ROHM	
D871	ISS113	SILICON ROHM	
D872	ISS113	SILICON ROHM	
D873	ISS113	SILICON ROHM	

CAPACITORS

▲	ITEM	PART NUMBER	DESCRIPTION	AREA
C101	QFV81HJ-104	0.1MF 50V T.FILM		
C102	QFV81HJ-104	0.1MF 50V T.FILM		
C103	QETB1CM-228	2200MF 16V ELECTRO		
C104	QETB1CM-228	2200MF 16V ELECTRO		
C105	QETB1CM-227	220MF 16V ELECTRO		
C106	QETB1CM-227	220MF 16V ELECTRO		
C107	QETB1HM-225	2.2MF 50V ELECTRO		
C108	QETB1HM-225	2.2MF 50V ELECTRO		
C109	QETB1AM-476	47MF 10V ELECTRO		
C110	QETB1AM-476	47MF 10V ELECTRO		
C119	QETB0JM-477	470MF 6.3V ELECTRO		
C120	QETB1HM-107	100MF 50V ELECTRO		
C131	QETB1CM-227	220MF 16V ELECTRO		
C132	QETB1CM-226	22MF 16V ELECTRO		
C201	QETB1EM-106	10MF 25V ELECTRO		
C202	QCHB1EZ-223	0.022MF 25V CERAMIC		
C203	QETB1HM-475	4.7MF 50V ELECTRO		
C204	QEKS1HM-475	4.7MF 50V ELECTRO		
C206	QCHB1EZ-223	0.022MF 25V CERAMIC		
C207	QCBB1HK-331	330PF 50V CERAMIC		
C251	QCHB1EZ-223	0.022MF 25V CERAMIC		
C252	QCHB1EZ-223	0.022MF 25V CERAMIC		
C253	QCBB1HK-181	180PF 50V CERAMIC		
C254	QBB1HK-181	180PF 50V CERAMIC		
C257	QETB1HM-475	4.7MF 50V ELECTRO		
C258	QETB1HM-475	4.7MF 50V ELECTRO		
C269	QFN81HJ-103	0.01MF 50V MYLAR		
C270	QFN81HJ-103	0.01MF 50V MYLAR		
C271	QCF21HP-223	0.022MF 50V CERAMIC		
C272	QCF21HP-223	0.022MF 50V CERAMIC		
C273	QCF21HP-223	0.022MF 50V CERAMIC		
C300	QCZ0205-155	1.5MF 25V CERAMIC		
C301	QCZ0205-155	1.5MF 25V CERAMIC		
C302	QETB1AM-227	220MF 10V ELECTRO		
C303	QCZ0205-155	1.5MF 25V CERAMIC		
C304	QETB0JM-227	220MF 6.3V ELECTRO		
C305	QETB0JM-227	220MF 6.3V ELECTRO		
C306	QCZ0205-155	1.5MF 25V CERAMIC		
C308	QCT30CH-120	12PF 50V CERAMIC		
C309	QCT30CH-359	3.9PF 50V CERAMIC		
C310	QCSB1HJ-270	27PF 50V CERAMIC		
C316	QCHB1EZ-223	0.022MF 25V CERAMIC		
C317	QCT30CH-100	10PF 50V CERAMIC		
C321	QFN81HJ-122	1200PF 50V MYLAR		
C322	QFN81HJ-122	1200PF 50V MYLAR		
C323	QCS21HJ-221	220PF 50V CERAMIC		
C324	QCS21HJ-221	220PF 50V CERAMIC		
C325	QFN81HJ-392	3900PF 50V MYLAR		
C326	QFN81HJ-392	3900PF 50V MYLAR		
C327	QCS21HJ-121	120PF 50V CERAMIC		
C328	QCS21HJ-121	120PF 50V CERAMIC		
C329	QETB1CM-226	22MF 16V ELECTRO		
C330	QETB1CM-226	22MF 16V ELECTRO		
C331	QFN81HJ-562	5600PF 50V MYLAR		
C332	QFN81HJ-562	5600PF 50V MYLAR		
C333	QFN81HJ-472	4700PF 50V MYLAR		
C334	QFN81HJ-472	4700PF 50V MYLAR		
C341	QCHB1EZ-223	0.022MF 25V CERAMIC		
C342	QCHB1EZ-223	0.022MF 25V CERAMIC		
C343	QCHB1EZ-223	0.022MF 25V CERAMIC		
C344	QCHB1EZ-223	0.022MF 25V CERAMIC		
C345	QETB1CM-227	220MF 16V ELECTRO		
C346	QETB1CM-227	220MF 16V ELECTRO		
C401	QCZ0205-155	1.5MF 25V CERAMIC		
C402	QFN81HJ-473	0.047MF 50V MYLAR		
C403	QCHB1EZ-223	0.022MF 25V CERAMIC		
C404	QFN81HJ-152	1500PF 50V MYLAR		
C405	QCF21HP-103	0.01MF 50V CERAMIC		
C406	QCZ0205-155	1.5MF 25V CERAMIC		
C407	QCS21HJ-120	12PF 50V CERAMIC		
C451	QCZ0205-155	1.5MF 25V CERAMIC		
C455	QCHB1EZ-223	0.022MF 25V CERAMIC		
C457	QCF21HP-223	0.022MF 50V CERAMIC		
C501	QCHB1EZ-223	0.022MF 25V CERAMIC		
C502	QCS21HJ-100	10PF 50V CERAMIC		
C503	QCS21HJ-100	10PF 50V CERAMIC		
C504	QETB1AM-476	47MF 10V ELECTRO		
C505	QCS21HJ-820	82PF 50V CERAMIC		
C506	QCS21HJ-101	100PF 50V CERAMIC		
C507	QFN81HJ-104	0.1MF 50V T.FILM		
C508	QCZ0205-155	1.5MF 25V CERAMIC		
C509	QCS21HJ-220	22PF 50V CERAMIC		
C510	QCHB1EZ-223	0.022MF 25V CERAMIC		
C601	QFN81HJ-182	1800PF 50V MYLAR		
C603	QFN81HJ-222	2200PF 50V MYLAR		
C604	QFN81HJ-222	2200PF 50V MYLAR		
C605	QCHB1EZ-223	0.022MF 25V CERAMIC		
C606	QFN81HJ-333	0.033MF 50V MYLAR		
C607	QFN81HJ-103	0.01MF 50V MYLAR		
C608	QCHB1EZ-223	0.022MF 25V CERAMIC		
C609	QFN81HJ-333	0.033MF 50V MYLAR		
C610	QCZ0205-155	1.5MF 25V CERAMIC		
C611	QCHB1EZ-223	0.022MF 25V CERAMIC		
C612	QFV81HJ-104	0.1MF 50V T.FILM		
C614	QFN81HJ-104	0.1MF 50V MYLAR		

▲ : SAFETY PARTS

▲ : SAFETY PARTS

CAPACITORS

△	ITEM	PART NUMBER	DESCRIPTION	AREA
C615	QFN81HJ-333	0.033MF 50V	MYLAR	
C616	QFN81HJ-473	0.047MF 50V	MYLAR	
C617	QFN81HJ-473	0.047MF 50V	MYLAR	
C618	QFN81HJ-473	0.047MF 50V	MYLAR	
C619	QETB1HM-335	3.3MF 50V	ELECTRO	
C620	QFN81HJ-104	0.1MF 50V	MYLAR	
C622	QCF21HP-223	0.022MF 50V	CERAMIC	
C623	QFN81HJ-563	0.056MF 50V	MYLAR	
C624	QETB1EM-106	10MF 25V	ELECTRO	
C626	QFN81HJ-103	0.01MF 50V	MYLAR	
C627	QFN81HJ-103	0.01MF 50V	MYLAR	
C629	QFN81HJ-333	0.033MF 50V	MYLAR	
C701	QCBB1HK-101	100PF 50V	CERAMIC	
C824	QCF21HP-223	0.022MF 50V	CERAMIC	
C825	QCF21HP-223	0.022MF 50V	CERAMIC	
C840	QCHB1EZ-223	0.022MF 25V	CERAMIC	
C841	QCHB1EZ-223	0.022MF 25V	CERAMIC	
C871	QCHB1EZ-223	0.022MF 25V	CERAMIC	
C872	QCHB1EZ-223	0.022MF 25V	CERAMIC	
C874	QETB1HM-105	1MF 50V	ELECTRO	
C875	QCF21HP-223	0.022MF 50V	CERAMIC	

RESISTORS

△	ITEM	PART NUMBER	DESCRIPTION	AREA
R304	QRD167J-271	270	1/6W CARBON	
R305	QRD167J-182	1.8K	1/6W CARBON	
R306	QRV144F-1802	18K	1/4W M.FILM	
R307	QRV144F-1802	18K	1/4W M.FILM	
R308	QRV144F-1802	18K	1/4W M.FILM	
R309	QRV144F-1802	18K	1/4W M.FILM	
R310	QRD167J-182	1.8K	1/6W CARBON	
R311	QRD167J-271	270	1/6W CARBON	
R312	QRV144F-1802	18K	1/4W M.FILM	
R313	QRV144F-1802	18K	1/4W M.FILM	
R314	QRD167J-330	33	1/6W CARBON	
R315	QRD167J-560	56	1/6W CARBON	
R316	QRD167J-271	270	1/6W CARBON	
R317	QRD167J-155	1.5M	1/6W CARBON	
R318	QRD167J-102	1K	1/6W CARBON	
R319	QRD167J-681	680	1/6W CARBON	
R320	QRD167J-121	120	1/6W CARBON	
R321	QRD167J-182	1.8K	1/6W CARBON	
R322	QRD167J-182	1.8K	1/6W CARBON	
R323	QRD167J-182	1.8K	1/6W CARBON	
R324	QRD167J-182	1.8K	1/6W CARBON	
R325	QRD167J-123	12K	1/6W CARBON	
R326	QRD167J-123	12K	1/6W CARBON	
R327	QRD167J-123	12K	1/6W CARBON	
R328	QRD167J-123	12K	1/6W CARBON	
R329	QRD167J-123	12K	1/6W CARBON	
R330	QRD167J-123	12K	1/6W CARBON	
R331	QRD167J-272	2.7K	1/6W CARBON	
R332	QRD167J-272	2.7K	1/6W CARBON	
R335	QRD167J-273	27K	1/6W CARBON	
R336	QRD167J-273	27K	1/6W CARBON	
R337	QRD167J-331	330	1/6W CARBON	
R338	QRD167J-331	330	1/6W CARBON	
R339	QRD167J-331	330	1/6W CARBON	
R340	QRD167J-331	330	1/6W CARBON	
R341	QRD161J-221	220	1/6W CARBON	
R342	QRD161J-221	220	1/6W CARBON	
R345	QRD161J-221	220	1/6W CARBON	
R346	QRD161J-221	220	1/6W CARBON	
R371	QRD167J-103	10K	1/6W CARBON	
R372	QRD167J-103	10K	1/6W CARBON	
R373	QRD167J-684	680K	1/6W CARBON	
R374	QRD167J-473	47K	1/6W CARBON	
R401	QRD167J-332	3.3K	1/6W CARBON	
R402	QRD167J-682	6.8K	1/6W CARBON	
R403	QRD167J-103	10K	1/6W CARBON	
R404	QRD167J-103	10K	1/6W CARBON	
R405	QRD167J-102	1K	1/6W CARBON	
R406	QRD167J-102	1K	1/6W CARBON	
R407	QRD167J-102	1K	1/6W CARBON	
R408	QRD167J-102	1K	1/6W CARBON	
R409	QRD167J-560	56	1/6W CARBON	
R501	QRD167J-102	1K	1/6W CARBON	
R504	QRD167J-183	18K	1/6W CARBON	
R505	QRD167J-183	18K	1/6W CARBON	
R506	QRD167J-121	120	1/6W CARBON	
R507	QRD167J-103	10K	1/6W CARBON	
R508	QRD167J-332	3.3K	1/6W CARBON	
R509	QRD167J-822	8.2K	1/6W CARBON	
R510	QRD167J-113	11K	1/6W CARBON	
R511	QRD167J-104	100K	1/6W CARBON	
R514	QRD167J-103	10K	1/6W CARBON	
R601	QRD167J-472	4.7K	1/6W CARBON	
R602	QRD167J-472	4.7K	1/6W CARBON	
R605	QRD167J-102	1K	1/6W CARBON	
R606	QRD167J-104	100K	1/6W CARBON	
R610	QRD167J-224	220K	1/6W CARBON	
R611	QRD167J-2R2	2.2	1/6W CARBON	
R612	QRD167J-683	68K	1/6W CARBON	
R613	QRD167J-104	100K	1/6W CARBON	
R614	QRD167J-2R2	2.2	1/6W CARBON	
R615	QRD167J-224	220K	1/6W CARBON	
R616	QRD167J-273	27K	1/6W CARBON	
R617	QRD167J-332	3.3K	1/6W CARBON	
R618	QRD167J-514	510K	1/6W CARBON	
R619	QRD167J-2R2	2.2	1/6W CARBON	
R620	QRD167J-562	5.6K	1/6W CARBON	
R621	QRD167J-683	68K	1/6W CARBON	
R622	QRD167J-124	120K	1/6W CARBON	
R623	QRD167J-472	4.7K	1/6W CARBON	
R626	QRD167J-153	15K	1/6W CARBON	
R627	QRD167J-333	33K	1/6W CARBON	
R628	QRD167J-752	7.5K	1/6W CARBON	
R629	QRD167J-752	7.5K	1/6W CARBON	
R630	QRD167J-333	33K	1/6W CARBON	
R631	QRD167J-470	47	1/6W CARBON	
R638	QRD167J-184	180K	1/6W CARBON	
R701	QRD161J-221	220	1/6W CARBON	
R702	QRD161J-221	220	1/6W CARBON	
R703	QRD167J-101	100	1/6W CARBON	
R820	QRD161J-221	220	1/6W CARBON	
R821	QRD161J-221	220	1/6W CARBON	
R822	QRD161J-221	220	1/6W CARBON	
R823	QRD161J-221	220	1/6W CARBON	
R824	QRD161J-221	220	1/6W CARBON	

△ : SAFETY PARTS

△ : SAFETY PARTS

RESISTORS

▲	ITEM	PART NUMBER	DESCRIPTION	AREA
	R825	QRD161J-221	220 1/6W CARBON	
	R826	QRD167J-101	100 1/6W CARBON	
	R841	QRD167J-243	24K 1/6W CARBON	
	R842	QRD167J-183	18K 1/6W CARBON	
	R843	QRD167J-203	20K 1/6W CARBON	
	R844	QRD167J-183	18K 1/6W CARBON	
	R845	QRD167J-820	82 1/6W CARBON	
	R871	QRD167J-273	27K 1/6W CARBON	
	R872	QRD167J-223	22K 1/6W CARBON	
	R873	QRD167J-303	30K 1/6W CARBON	
	R874	QRD167J-103	10K 1/6W CARBON	
	R876	QRD167J-473	47K 1/6W CARBON	
	R877	QRD167J-752	7.5K 1/6W CARBON	
	R879	QRD161J-221	220 1/6W CARBON	
	R881	QRD167J-393	39K 1/6W CARBON	
	R882	QRD167J-123	12K 1/6W CARBON	
	R883	QRD167J-153	15K 1/6W CARBON	
	RA201	QRB049J-103	10K 1/10W R.NETWORK	
	VR271	QVAB79C-E53B	5K VARIABLE	
	VR512	QVPA601-203A	20K VARIABLE	
	VR513	QVPA601-203A	20K VARIABLE	
	VR603	QVPA601-203A	20K VARIABLE	
	VR604	QVPA601-203A	20K VARIABLE	

OTHERS

▲	ITEM	PART NUMBER	DESCRIPTION	AREA
	FW101	EWR36B-40SST	FLAT WIRE(6PIN)	
	FW201	EWR36B-20SST	FLAT WIRE(6PIN)	
	FW202	EWR36B-30SST	FLAT WIRE(6PIN)	
	FW203	EWR33B-10LST	FLAT WIRE(3PIN)	
	FW801	EWR36B-10KST	FLAT WIRE(6PIN)	
	FW803	EWR37B-10KST	FLAT WIRE(7PIN)	
	FW831	EWR37B-10KST	FLAT WIRE(7PIN)	
	JT271	EMV7122-103	CONNECTOR	

▲ : SAFETY PARTS

OTHERS

▲	ITEM	PART NUMBER	DESCRIPTION	AREA
		E3400-439	FELT SPACER	
		E70306-001	HEAT SINK	
		E70859-001	EARTH PLATE	
		E75819-001	SUPPORT HOLDER	
		E75820-001	SUPPORT HOLDER	
		SBSE3008Z	SCREW	
J201		EMV7123-035	CONNECTOR(35PIN)	
J202		EMV7123-035R	CONNECTOR(35PIN)	
J271		QMS6A20-E21H	HEADPHONE JACK	
J301		EMN00TV-214A	2P PIN JACK	
J451		GP1F32T	OPTICAL JACK	
J701		QMS3501-020	MINI JACK	
L271		EQL4004-1R0	INDUCTOR	
P101		QMCB001-E02H	AC SOCKET	A BBS
P101		QMCB001-E02HBS	AC SOCKET	E
P501		EMV5109-010A	PLUG ASSY(10PIN)	
P502		EMV5109-004A	PLUG ASSY(4PIN)	
S201		ESP0001-018	TACT SWITCH(POWER)	
S202		ESP0001-018	TACT SWITCH(DISPLAY)	
S203		ESP0001-018	TACT SWITCH(REPEAT)	
S204		ESP0001-018	TACT SWITCH(INTRO)	
S205		ESP0001-018	TACT SWITCH(P.MODE)	
S206		ESP0001-018	TACT SWITCH(CALL)	
S207		ESP0001-018	TACT SWITCH(MEMORY)	
S208		ESP0001-018	TACT SWITCH(SIDE A/B)	
S209		ESP0001-018	TACT SWITCH(EDIT)	
S210		ESP0001-018	TACT SWITCH(EJECT)	
S211		ESP0001-018	TACT SWITCH(PLAY/PAUSE)	
S212		ESP0001-018	TACT SWITCH(STOP/CANCEL)	
S213		ESP0001-018	TACT SWITCH(▶)	
S214		ESP0001-018	TACT SWITCH(◀)	
S215		ESP0001-018	TACT SWITCH(OPEN/CLOSE)	
S216		ESP0001-018	TACT SWITCH(DISC 6)	
S217		ESP0001-018	TACT SWITCH(DISC 5)	
S218		ESP0001-018	TACT SWITCH(DISC 4)	
S219		ESP0001-018	TACT SWITCH(DISC 3)	
S220		ESP0001-018	TACT SWITCH(DISC 2)	
S221		ESP0001-018	TACT SWITCH(DISC 1)	
S222		ESP0001-018	TACT SWITCH(DISC 9)	
S223		ESP0001-018	TACT SWITCH(+10)	
S224		ESP0001-018	TACT SWITCH(10)	
S225		ESP0001-018	TACT SWITCH(9)	
S226		ESP0001-018	TACT SWITCH(8)	
S227		ESP0001-018	TACT SWITCH(7)	
S228		ESP0001-018	TACT SWITCH(6)	
S229		ESP0001-018	TACT SWITCH(5)	
S230		ESP0001-018	TACT SWITCH(4)	
S231		ESP0001-018	TACT SWITCH(3)	
S232		ESP0001-018	TACT SWITCH(2)	
S233		ESP0001-018	TACT SWITCH(1)	
X201		ECX0060-000EM	RESONATOR	
X301		ECX0169-344EA	RESONATOR	
CP101		ICP-N5	I.C. PROTECTOR	
FL201		ELU0001-132	FL TUBE	

▲ : SAFETY PARTS

Accessories List

⚠	Part Number	Part Name	Q'ty	Description	Areas
	E30580-1951A E30580-1951ABS E30580-1952A E30580-1953A E30580-1953A	INSTRUCTION BOOK INSTRUCTION BOOK INSTRUCTION BOOK INSTRUCTION BOOK INSTRUCTION BOOK	1 1 1 1 1		A BS EN EF G
	BT20060 BT-20134 BT-20122 BT-20122-1 BT-20066A	WARRANTY CARD WARRANTY CARD WARRANTY CARD LTD STICKER EEC AGENCY	1 1 1 1 1		BS G A A BS
⚠	E43486-340A QMP25D0-183 QMP5520-1835BS QMP39F0-183 QMP39F0-183	SAFETY SHEET POWER CORD POWER CORD POWER CORD POWER CORD	1 1 1 1 1		BS A BS EF EN
⚠	QMP39F0-183 EWP302-013K EWP805-009K E26072-005 E407273-001	POWER CORD SIGNAL CORD PLUG CORD MAGAZINE MAGAZINE LABEL	1 1 1 1 1		G
	RM-SX509U RM-SX507UBATC UM-3(DJ)-2PSA E300196-010 E300196-010B	REMOTE CONTROLLER BATTERY COVER BATTERY ENVELOPE ENVELOPE	1 1 1 2 2		A BS
	E300196-010 E300196-010 E300196-010	ENVELOPE ENVELOPE ENVELOPE	2 2 2		EF EN G

⚠ SAFETY PARTS


The Marks for Designated Areas

A Australia
G Germany
No mark indicates all areas.

EN Scandinavia
BS the U.K.

EF Continental Europe

Packing Materials and Part Numbers



The Marks for Designated Areas

A	Australia	BS	the U.K.
EN	Scandinavia	EF	Continental Europe
G	Germany	No mark indicates all areas.	

— MEMO —

— MEMO —

PARTS LIST


Note : All printed circuit boards and its assemblies are not available as service parts.

Contents

General Exploded View and Parts List	3 - 2
CD Changer Ass'y and Parts List	3 - 5
■ How to install the gears and pulley when servicing.	3-10
Printed Circuit Board Ass'y and Parts List	3-11
■ ENN-354 <input type="checkbox"/> Main & Front PC Board Ass'y	3-11
Accessories List	3-15
Packing Materials and Part Numbers	3-16

General Exploded View and Parts List

■ Exploded View



Parts List

⚠ Item	Part Number	Part Name	Q'ty	Description	Areas
1	EFP-XLM509TNE (S)	FRONT PANEL ASS'Y	1		
1-1	E102653-006	FRONT PANEL	1		
1-2	E308282-001	WINDOW SCREEN	1		
1-3	E72968-001	JVC MARK	1		
2	SDSG3006M	SCREW	6		
3	E74179-007	KNOB	1		
4	E75896-001	SPACER	2	FRONT FOOT	
5	E308284-001	HEADPHONE BRACKET	1		
6	SDFS2608Z	SCREW	13		
7	EWR135K-42TT	FLAT WIRE ASS'Y	1		
8	E25834-010	METAL COVER	1		
9	SBSG3008M	SCREW	2		
10	E406308-001	SPECIAL SCREW	4		
11	E102650-001	CHASSIS BASE	1		
12	E406472-003	FOOT ASSY	2	REAR	
13	SBST3008Z	SCREW	2	FOR REAR FOOT	
14	E308285-001	FITTING	1		
15	-----	CD CHANGER MECHANISM UNIT ASS'Y	1	SEE PAGE 3-5	
16	E406507-001	CAUTION LABEL	1		A
	E406507-001	CAUTION LABEL	1		C
	E406507-001	CAUTION LABEL	1		EF
	E406507-001	CAUTION LABEL	1		EN
	E406507-001	CAUTION LABEL	1		U
	E406507-001	CAUTION LABEL	1		UT
17	GBSG3008CC	SCREW	4		
18	ETP1010-51JA	POWER TRANSFORMER	1		J
	ETP1010-51JA	POWER TRANSFORMER	1		C
	ETP1010-51EA	POWER TRANSFORMER	1		A
	ETP1010-51EA	POWER TRANSFORMER	1		EF
	ETP1010-51EA	POWER TRANSFORMER	1		EN
	ETP1010-51LA	POWER TRANSFORMER	1		U
	ETP1010-51LA	POWER TRANSFORMER	1		UT
19	E65389-004	SPECIAL SCREW	2	FOR POWER TARANS.	
20	E207686-001	REAR PANEL	1		J
	E207686-002	REAR PANEL	1		C
	E207686-002	REAR PANEL	1		A
	E207686-002	REAR PANEL	1		EN
	E207686-003	REAR PANEL	1		EF
	E207686-003	REAR PANEL	1		U
	E207686-003	REAR PANEL	1		UT
—	E308453-001	RATING LABEL	1		C
	E308453-002	RATING LABEL	1		EN
	E308453-002	RATING LABEL	1		EF
	E308287-025	RATING LABEL	1		UT
21	E73273-006	SPECIAL SCREW	7		
22	E72018-001	WIRE CLAMP	1		
23	E75217-001	WIRE CLAMP	1		
24	SBSF2608M	SCREW	2		U
	SBSF2608M	SCREW	2		UT
25	SBST3006Z	SCREW	2		
—	E307570-001	NUMBER LABEL	1		J
	E61029-005	NUMBER LABEL	1		C
	E61029-005	NUMBER LABEL	1		A
	E61029-005	NUMBER LABEL	1		EN
	E61029-005	NUMBER LABEL	1		EF

⚠ Item	Part Number	Part Name	Q'ty	Description	Areas
—	E61029-005	NUMBER LABEL	1		U
—	E61029-005	NUMBER LABEL	1		UT
—	E70891-001	LABEL	1		A
—	E70891-001	LABEL	1		EF
—	E70891-001	LABEL	1		EN
—	E70891-001	LABEL	1		U
—	E70891-001	LABEL	1		UT
—	E45858-002	LABEL	1		C
—	QZL1031-101	LABEL	1		EF
—	E70027-001	LABEL	1		EN


⚠ SAFETY PARTS

The Marks for Designated Areas
 J the U.S.A.
 EF Continental Europe
 No mark indicates all areas.

C Canada
 U Universal

A Australia
 UT Taiwan
 EN Scandinavia




CD Changer Ass'y and Parts List



Item	Part Number	Part Name	Q'ty	Description	Areas
1	30100101T	CHASSIS BASE	1		
2	30050115T	GUIDE BOSS	2		
3	300501302T	PRINTED CIRCUIT BOARD A ASSY	1		
4	301001301T	PRINTED CIRCUIT BOARD D ASSY	1		
5	300501304T	PRINTED CIRCUIT BOARD P ASSY	1		
6	301002502T	ELEVATOR ARM A ASSY	3		
7	301002503T	ELEVATOR SIDE ARM B ASSY	2		
8	301002504T	ELEVATOR FRONT ARM A ASSY	1		
9	30100221T	CAM LEVER SPRING	1		
10	30100222T	CS COLLAR SCREW	1		
11	30100223T	CAM SPRING	1		
12	30100202T	LIFT CAM	1		
13	301002501T	ELEVATOR MOTOR BRACKET ASSY	1		
14	RF-370C-15370	DC MOTOR	2	LOADING , ELEVATOR	
15	30100210T	ELEVATOR GEAR B	2		
16	30100211T	ELEVATOR GEAR C	1		
17	30100212T	ELEVATOR GEAR C	1		
18	640101204T	LEAF SWITCH	2		
19	30100204T	CAM SLIDER	1		
20	30100205T	CAM SPRING PLATE	1		
21	30100206T	CAM LEVER	1		
22	30100207T	CAM ROLLER	1		
23	30100301T	GUIDE BASE	1		
24	30100311T	ELEVATOR SLIDE LEVER	1		
25	30100312T	ELEVATOR SLIDE LEVER SPRING	1		
26	30100303T	MAGAZINE GUIDE	1	LEFT	
27	30100304T	MAGAZINE GUIDE	1		
28	30100305T	GUIDE COVER	1		
29	30050309T	TRAY STOPPER	1		
30	30100310T	RELEASE LEVER	1		
31	30100308T	ELEVATOR KICK LEVER	1		
32	30100307T	LOCK LEVER	1		
33	30100309T	ELEVATOR KICK LEVER SPRING	1		
34	30100313T	RELEASE LEVER SPRING	1		
35	30100306T	CAM STABILIZER	1		
36	64020403T	PUSH SWITCH	4		
37	30050508T	FEED GEAR A	2		
38	301005501T	FEED RAIL ASSY	1		
39	30100504T	HOOK SLIDE GEAR	1		
40	30100505T	SLIDE GEAR PLATE	1		
41	30050738T	TURNTABLE BASE	1		
42	60020705T	SPINDLE MOTOR	1		
43	30050729T	TURNTABLE	1		
44	30050713T	TURNTABL R PLATE	1		
45	30050742T	CONTROLLER SPRING	1		
46	30050721T	FLOATING RUBBER	3		
47	30050715T	FLOATING SPRING (B)	2		
48	30050743T	FLOATING SCREW	3		
49	30050740T	FLOATING SPRING	1		
50	60021102T	FEED.MOTOR	1		
51	30050709T	MOTOR PULLEY	1		
52	30050714T	FEED MOTOR BELT	1		
53	30050737T	PICK UP SUPPORT	1		
54	30050724T	SHAFT HOLDER A	1		
55	300507303T	FEED SCREW ASSY	1		

Item	Part Number	Part Name	Q'ty	Description	Areas
56	30050728T	PICK UP SHAFT	1		
57	30050735T	FEED NUT HOLDER	1		
58	30050739T	FEED NUT SPRING	1		
59	EWS26A-B921	SOCKET WIRE	1		
60	OPTIMA-5S	PICK UP	1		
61	EWS264-B924	SOCKET WIRE ASSY	1		
62	301008503T	RAIL BASE ASSY	1		
63	30100802T	RAIL	1	LEFT	
64	30100803T	RAIL	1	RIGHT	
65	30100804T	HOOK LEVER	1		
66	301008502T	LP BRACKET ASSY	1		
67	301008301T	MAGAZINE HOLDER ASSY	1		
68	30050114T	CHASSIS SUPPORT	1		
69	30050725T	SHAFT HOLDER B	1		
70	12030105T	TIE BAND	4		
71	300507305T	TURNTABLE BASE ASSY	1		
72	301004502T	PLUS 1 BASE ASSY	1		
73	301004302T	PLUS 1 RAIL BASE ASSY	1		
74	30100415T	STOPPER SPRING	1		
75	30050416T	STOPPER	1		
76	30100411T	PIUS 1 BELT	1		
77	30100403T	PLUS 1 GEAR A	2		
78	30100404T	PLUS 1 GEAR B	1		
79	30100515T	FEED GEAR C	2		
80	30100506T	FEED GEAR D	1		
81	30100516T	FEED GEAR E	3		
82	30100413T	FEED GEAR D SPRING	1		
83	30100412T	FEED GEAR E SPRING	1		
84	30100414T	SWITCH ACTUATOR	1		
85	30100418T	PLUS 1 SLIDE RAIL	1		
86	30101015T	WIRE	1		
87	E26554-005	TRAY	1		
88	SPSK1722M	SCREW	2		
89	9C0420253T	SCREW	1		
90	9C0720601T	SCREW	2		
91	9C0420303T	SCREW	1		
92	9C0420403T	SCREW	2		
93	9P0420031T	SCREW	4		
94	9P0220031T	SCREW	2		
95	9P0230041T	SCREW	2		
96	9P3320032T	SCREW	1		
97	9P0420051T	SCREW	3		
98	9P0420041T	SCREW	3		
99	9W0250110T	WASHER	14		
100	9W0113080T	WASHER	3		
101	REE3000X	E.RING	3		
102	9W0640040T	WASHER	3		
103	301002301T	ELEVATOR MOTOR ASSY	2		
104	300507306T	FEED MOTOR ASSY	1		
105	301002302T	CAM SLIDE ASSY	1		
106	30051007T	WIRE	1	ORANGE	
107	30051011T	WIRE	2	YELLOW	
108	30051014T	WIRE	1	BLUE	
109	30101001T	WIRE	2		
110	30101002T	WIRE	1	YELLOW	
111	30101003T	WIRE	1	BRACK	


Item	Part Number	Part Name	Q'ty	Description	Areas
112	30101005T	WIRE	1	BRACK	
113	30101006T	WIRE	1	RED	
114	30101007T	WIRE	1		
115	30101008T	WIRE	1		

■ How to install the gears and pulley when servicing.**1. Elevator Motor , Loading Motor****2. Loading Motor for single tray****3. Feed Motor**

Printed Circuit Board Ass'y and Parts List

■ENN-354 □ Main & Front PC Board Ass'y

Note : ENN-354 □ varies according to the areas employed. See note (1) when placing an order.



Note (1)

PC Board Ass'y	Designated Areas
ENN-354 [A]	Australia
ENN-354 [C]	Canada
ENN-354 [D]	the U.S.A.
ENN-354 [E]	Scandinavia, Germany Continental Europe
ENN-354 [F]	Universal Type, Taiwan

TRANSISTORS

▲ ITEM	PART NUMBER	DESCRIPTION		AREA
Q101	2SB1187(E,F)	SILICON	ROHM	
Q102	2SC2060(Q,R)	SILICON	ROHM	
Q103	2SD1302(S,T)	SILICON	MATSUSHITA	
Q104	2SA933S(R,S)	SILICON	ROHM	
Q105	2SB1357(E,F)	SILICON	ROHM	
Q106	2SD2144S(VW)	SILICON	ROHM	
Q107	2SD2144S(VW)	SILICON	ROHM	
Q108	DTA114YS	SILICON	ROHM	
Q114	2SA733A(P,Q)	SILICON	NEC	
Q131	2SA933S(R,S)	SILICON	ROHM	
Q132	2SD2144S(VW)	SILICON	ROHM	
Q201	DTA114YS	SILICON	ROHM	
Q202	DTC144ES	SILICON	ROHM	
Q203	DTC114YS	SILICON	ROHM	
Q371	2SD1302(S,T)	SILICON	MATSUSHITA	
Q372	2SD1302(S,T)	SILICON	MATSUSHITA	
Q601	2SD2037(E,F)	SILICON	ROHM	
Q602	2SA934(Q,R)	SILICON	ROHM	
Q603	2SD2037(E,F)	SILICON	ROHM	
Q604	2SB1357(E,F)	SILICON	ROHM	
Q605	DTC144ES	SILICON	ROHM	
Q871	2SC2060(Q,R)	SILICON	ROHM	
Q872	2SA934(Q,R)	SILICON	ROHM	
Q875	DTC144ES	SILICON	ROHM	

I. C. S.

▲ ITEM	PART NUMBER	DESCRIPTION		AREA
IC201	MN171602JHC	I.C.		
IC202	MN1281(P,Q)	I.C.	MATSUSHITA	
IC203	GP1U571X	I.C.	SHARP	
IC251	VC4580D	I.C.	DAINICHI	
IC301	MN35500	I.C.		
IC303	VC4580D	I.C.	DAINICHI	
IC304	VC4580D	I.C.	DAINICHI	
IC401	CXD2500BQ	I.C.		
IC501	CXA1571S	I.C.	1680	
IC601	CXA1372S	I.C.	1680	
IC602	STA341M(A)	I.C.	SANKEN	
IC802	M5218AL	I.C.	MITSUBISHI	
IC871	M5218AL	I.C.	MITSUBISHI	

DIODES

▲ ITEM	PART NUMBER	DESCRIPTION		AREA
D101	S1VB20F	SILICON	SINDENGEN	
D102	MTZ5.6JB	ZENER	ROHM	
D103	MTZ5.6JB	ZENER	ROHM	
D113	1SR139-200	SILICON	ROHM	
D114	MTZ33JC	ZENER	ROHM	
D131	ISS133	SILICON	ROHM	
D132	ISS133	SILICON	ROHM	
D201	ISS133	SILICON	ROHM	
D202	ISS133	SILICON	ROHM	
D203	ISS119	SILICON	HITACHI	
D204	ISS119	SILICON	HITACHI	
D205	ISS119	SILICON	HITACHI	
D206	ISS119	SILICON	HITACHI	
D207	ISS119	SILICON	HITACHI	
D208	ISS119	SILICON	HITACHI	
D209	ISS119	SILICON	HITACHI	
D210	ISS119	SILICON	HITACHI	
D211	ISS119	SILICON	HITACHI	
D212	SLH-56VC50F130	L.E.D.	ROHM	
D213	ISS133	SILICON	ROHM	
D870	ISS133	SILICON	ROHM	
D871	ISS133	SILICON	ROHM	
D872	ISS133	SILICON	ROHM	
D873	ISS133	SILICON	ROHM	

CAPACITORS

▲ ITEM	PART NUMBER	DESCRIPTION		AREA
C101	QFV81HJ-104	0.1MF	50V T.FILM	
C102	QFV81HJ-104	0.1MF	50V T.FILM	
C103	QETB1CM-228	2200MF	16V ELECTRO	A
C103	QETB1CM-228	2200MF	16V ELECTRO	C
C103	QETB1CM-228	2200MF	16V ELECTRO	D
C103	QETB1CM-228	2200MF	16V ELECTRO	E
C103	QETB1CM-338	3300PF	16V ELECTRO	F
C104	QETB1CM-228	2200MF	16V ELECTRO	
C105	QETB1CM-227	220MF	16V ELECTRO	
C106	QETB1CM-227	220MF	16V ELECTRO	
C107	QETB1HM-225	2.2MF	50V ELECTRO	
C108	QETB1HM-225	2.2MF	50V ELECTRO	
C109	QETB1AM-476	47MF	10V ELECTRO	
C110	QETB1AM-476	47MF	10V ELECTRO	
C119	QETBOJM-477	470MF	6.3V ELECTRO	
C120	QETB1HM-107	100MF	50V ELECTRO	
C131	QETB1CM-227	220MF	16V ELECTRO	
C132	QETB1CM-226	22MF	16V ELECTRO	
C201	QETB1EM-106	10MF	25V ELECTRO	
C202	QCHB1EZ-223	0.022MF	25V CERAMIC	
C203	QETB1HM-475	4.7MF	50V ELECTRO	
C204	QEKS1HM-475	4.7MF	50V ELECTRO	
C206	QCHB1EZ-223	0.022MF	25V CERAMIC	
C207	QCBB1HK-331	330PF	50V CERAMIC	
C251	QCHB1EZ-223	0.022MF	25V CERAMIC	
C252	QCHB1EZ-223	0.022MF	25V CERAMIC	
C253	QCBB1HK-181	180PF	50V CERAMIC	
C254	QCBB1HK-181	180PF	50V CERAMIC	
C257	QETB1HM-475	4.7MF	50V ELECTRO	
C258	QETB1HM-475	4.7MF	50V ELECTRO	
C269	QFN81HJ-103	0.01MF	50V MYLAR	
C270	QFN81HJ-103	0.01MF	50V MYLAR	
C271	QCF21HP-223	0.022MF	50V CERAMIC	
C272	QCF21HP-223	0.022MF	50V CERAMIC	
C273	QCF21HP-223	0.022MF	50V CERAMIC	
C300	QCZO205-155	1.5MF	25V CERAMIC	
C301	QCZO205-155	1.5MF	25V CERAMIC	
C302	QETB1AM-227	220MF	10V ELECTRO	
C303	QCZO205-155	1.5MF	25V CERAMIC	
C304	QETBOJM-227	220MF	6.3V ELECTRO	
C305	QETBOJM-227	220MF	6.3V ELECTRO	
C306	QCZO205-155	1.5MF	25V CERAMIC	
C308	QCT30CH-120	12PF	50V CERAMIC	
C309	QCT30CH-3R9	3.9PF	50V CERAMIC	
C310	QCSB1HJ-270	27PF	50V CERAMIC	
C316	QCHB1EZ-223	0.022MF	25V CERAMIC	
C317	QCT30CH-100	10PF	50V MYLAR	
C321	QFN81HJ-122	1200PF	50V MYLAR	
C322	QFN81HJ-122	1200PF	50V MYLAR	
C323	QCS21HJ-221	220PF	50V CERAMIC	
C324	QCS21HJ-221	220PF	50V CERAMIC	
C325	QFN81HJ-392	3900PF	50V MYLAR	
C326	QFN81HJ-392	3900PF	50V MYLAR	
C327	QCS21HJ-121	120PF	50V CERAMIC	
C328	QCS21HJ-121	120PF	50V CERAMIC	
C329	QETB1CM-226	22MF	16V ELECTRO	
C330	QETB1CM-226	22MF	16V ELECTRO	
C331	QFN81HJ-562	5600PF	50V MYLAR	
C332	QFN81HJ-562	5600PF	50V MYLAR	
C333	QFN81HJ-472	4700PF	50V MYLAR	
C334	QFN81HJ-472	4700PF	50V MYLAR	
C341	QCHB1EZ-223	0.022MF	25V CERAMIC	
C342	QCHB1EZ-223	0.022MF	25V CERAMIC	
C343	QCHB1EZ-223	0.022MF	25V CERAMIC	
C344	QCHB1EZ-223	0.022MF	25V CERAMIC	
C345	QETB1CM-227	220NF	16V ELECTRO	
C346	QETB1CM-227	220MF	16V ELECTRO	
C401	QCZO205-155	1.5MF	25V CERAMIC	
C402	QFN81HJ-473	0.047MF	50V MYLAR	
C403	QCHB1EZ-223	0.022MF	25V CERAMIC	
C404	QFN81HJ-152	1500PF	50V MYLAR	
C405	QCF21HP-103	0.01MF	50V CERAMIC	
C406	QCZO205-155	1.5MF	25V CERAMIC	
C407	QCS21HJ-120	12PF	50V CERAMIC	
C451	QCZO205-155	1.5MF	25V CERAMIC	
C455	QCHB1EZ-223	0.022MF	25V CERAMIC	
C457	QCF21HP-223	0.022MF	50V CERAMIC	
C501	QCHB1EZ-223	0.022MF	25V CERAMIC	
C502	QCS21HJ-100	10PF	50V CERAMIC	
C503	QCS21HJ-100	10PF	50V CERAMIC	
C504	QETB1AM-476	47MF	10V ELECTRO	
C505	QCS21HJ-820	82PF	50V CERAMIC	
C506	QCS21HJ-101	100PF	50V CERAMIC	
C507	QFV81HJ-104	0.1MF	50V T.FILM	
C508	QCZO205-155	1.5MF	25V CERAMIC	
C509	QCS21HJ-220	22PF	50V CERAMIC	
C510	QCHB1EZ-223	0.022MF	25V CERAMIC	
C601	QFN81HJ-182	1800PF	50V MYLAR	
C603	QFN81HJ-222	2200PF	50V MYLAR	
C604	QFN81HJ-222	2200PF	50V MYLAR	
C605	QCHB1EZ-223	0.022MF	25V CERAMIC	
C606	QFN81HJ-333	0.033MF	50V MYLAR	
C607	QFN81HJ-103	0.01MF	50V MYLAR	
C608	QCHB1EZ-223	0.022MF	25V CERAMIC	
C609	QFN81HJ-333	0.033MF	50V MYLAR	

△ : SAFETY PARTS

△ : SAFETY PARTS

CAPACITORS

ITEM	PART NUMBER	DESCRIPTION	AREA
C610	QCZ0205-155	1.5MF 25V CERAMIC	
C611	QCHB1EZ-223	0.022MF 25V CERAMIC	
C613	QFV81HJ-104	0.1MF 50V T.FILM	
C614	QFN81HJ-104	0.1MF 50V MYLAR	
C615	QFN81HJ-333	0.033MF 50V MYLAR	
C616	QFN81HJ-473	0.047MF 50V MYLAR	
C617	QFN81HJ-473	0.047MF 50V MYLAR	
C618	QFN81HJ-473	0.047MF 50V MYLAR	
C619	QETB1HM-335	3.3MF 50V ELECTRO	
C620	QFN81HJ-104	0.1MF 50V MYLAR	
C622	QCF21HP-223	0.022MF 50V CERAMIC	
C623	QFN81HJ-563	0.056MF 50V MYLAR	
C624	QETB1EM-106	10MF 25V ELECTRO	
C626	QFN81HJ-103	0.01MF 50V MYLAR	
C627	QFN81HJ-103	0.01MF 50V MYLAR	
C629	QFN81HJ-333	0.033MF 50V MYLAR	
C701	QCBB1HK-101	100PF 50V CERAMIC	
C824	QCF21HP-223	0.022MF 50V CERAMIC	
C825	QCF21HP-223	0.022MF 50V CERAMIC	
C840	QCHB1EZ-223	0.022MF 25V CERAMIC	
C841	QCHB1EZ-223	0.022MF 25V CERAMIC	
C871	QCHB1EZ-223	0.022MF 25V CERAMIC	
C872	QCHB1EZ-223	0.022MF 25V CERAMIC	
C874	QETB1HM-105	1MF 50V ELECTRO	
C875	QCF21HP-223	0.022MF 50V CERAMIC	

RESISTORS

ITEM	PART NUMBER	DESCRIPTION	AREA
R263	QRD167J-561	560 1/6W CARBON	
R264	QRD167J-561	560 1/6W CARBON	
R269	QRD167J-150	15 1/6W CARBON	
R270	QRD167J-150	15 1/6W CARBON	
R271	QRD167J-390	39 1/6W CARBON	
R272	QRD167J-390	39 1/6W CARBON	
R273	QRD167J-270	27 1/6W CARBON	
R274	QRD167J-270	27 1/6W CARBON	
R300	QRD167J-560	56 1/6W CARBON	
R301	QRD167J-560	56 1/6W CARBON	
▲ R302	QRV144F-1802	18K 1/4W M.FILM	
▲ R303	QRV144F-1802	18K 1/4W M.FILM	
R304	QRD167J-271	270 1/6W CARBON	
R305	QRD167J-182	1.8K 1/6W CARBON	
▲ R306	QRV144F-1802	18K 1/4W M.FILM	
▲ R307	QRV144F-1802	18K 1/4W M.FILM	
▲ R308	QRV144F-1802	18K 1/4W M.FILM	
▲ R309	QRV144F-1802	18K 1/4W M.FILM	
R310	QRD167J-182	1.8K 1/6W CARBON	
R311	QRD167J-271	270 1/6W CARBON	
▲ R312	QRV144F-1802	18K 1/4W M.FILM	
▲ R313	QRV144F-1802	18K 1/4W M.FILM	
R314	QRD167J-330	33 1/6W CARBON	
R315	QRD167J-560	56 1/6W CARBON	
R316	QRD167J-271	270 1/6W CARBON	
R317	QRD167J-155	1.5M 1/6W CARBON	
R318	QRD167J-102	1K 1/6W CARBON	
R319	QRD167J-681	680 1/6W CARBON	
R320	QRD167J-121	120 1/6W CARBON	
R321	QRD167J-182	1.8K 1/6W CARBON	
R322	QRD167J-182	1.8K 1/6W CARBON	
R323	QRD167J-182	1.8K 1/6W CARBON	
R324	QRD167J-182	1.8K 1/6W CARBON	
R325	QRD167J-123	12K 1/6W CARBON	
R326	QRD167J-123	12K 1/6W CARBON	
R327	QRD167J-123	12K 1/6W CARBON	
R328	QRD167J-123	12K 1/6W CARBON	
R329	QRD167J-123	12K 1/6W CARBON	
R330	QRD167J-123	12K 1/6W CARBON	
R331	QRD167J-272	2.7K 1/6W CARBON	
R332	QRD167J-272	2.7K 1/6W CARBON	
R335	QRD167J-273	27K 1/6W CARBON	
R336	QRD167J-273	27K 1/6W CARBON	
R337	QRD167J-331	330 1/6W CARBON	
R338	QRD167J-331	330 1/6W CARBON	
R339	QRD167J-331	330 1/6W CARBON	
R340	QRD167J-331	330 1/6W CARBON	
R341	QRD161J-221	220 1/6W CARBON	
R342	QRD161J-221	220 1/6W CARBON	
R345	QRD161J-221	220 1/6W CARBON	
R346	QRD161J-221	220 1/6W CARBON	
R371	QRD167J-103	10K 1/6W CARBON	
R372	QRD167J-103	10K 1/6W CARBON	
R373	QRD167J-684	680K 1/6W CARBON	
R374	QRD167J-473	47K 1/6W CARBON	
R401	QRD167J-332	3.3K 1/6W CARBON	
R402	QRD167J-682	6.8K 1/6W CARBON	
R403	QRD167J-103	10K 1/6W CARBON	
R404	QRD167J-103	10K 1/6W CARBON	
R405	QRD167J-102	1K 1/6W CARBON	
R406	QRD167J-102	1K 1/6W CARBON	
R407	QRD167J-102	1K 1/6W CARBON	
R408	QRD167J-102	1K 1/6W CARBON	
R409	QRD167J-560	56 1/6W CARBON	
R501	QRD167J-102	1K 1/6W CARBON	
R504	QRD167J-183	18K 1/6W CARBON	
R505	QRD167J-183	18K 1/6W CARBON	
R506	QRD167J-121	120 1/6W CARBON	
R507	QRD167J-103	10K 1/6W CARBON	
R508	QRD167J-332	3.3K 1/6W CARBON	
R509	QRD167J-822	8.2K 1/6W CARBON	
R510	QRD167J-113	11K 1/6W CARBON	
R511	QRD167J-104	100K 1/6W CARBON	
R514	QRD167J-103	10K 1/6W CARBON	
R601	QRD167J-472	4.7K 1/6W CARBON	
R602	QRD167J-472	4.7K 1/6W CARBON	
R605	QRD167J-102	1K 1/6W CARBON	
R606	QRD167J-102	100K 1/6W CARBON	
R610	QRD167J-224	220K 1/6W CARBON	
R611	QRD167J-2R2	2.2 1/6W CARBON	
R612	QRD167J-683	68K 1/6W CARBON	
R613	QRD167J-104	100K 1/6W CARBON	
R614	QRD167J-2R2	2.2 1/6W CARBON	
R615	QRD167J-224	220K 1/6W CARBON	
R616	QRD167J-273	27K 1/6W CARBON	
R617	QRD167J-332	3.3K 1/6W CARBON	
R618	QRD167J-514	510K 1/6W CARBON	
R619	QRD167J-2R2	2.2 1/6W CARBON	
R620	QRD167J-562	5.6K 1/6W CARBON	
R621	QRD167J-683	68K 1/6W CARBON	
R622	QRD167J-124	120K 1/6W CARBON	
R623	QRD167J-472	4.7K 1/6W CARBON	
R626	QRD167J-153	15K 1/6W CARBON	
R627	QRD167J-333	33K 1/6W CARBON	
R628	QRD167J-752	7.5K 1/6W CARBON	

▲ : SAFETY PARTS

(No.20379)2-13

RESISTORS

△	ITEM	PART NUMBER	DESCRIPTION			AREA
	R629	QRD167J-752	7.5K	1/6W	CARBON	
	R630	QRD167J-333	33K	1/6W	CARBON	
	R631	QRD167J-470	47	1/6W	CARBON	
	R638	QRD167J-184	180K	1/6W	CARBON	
	R701	QRD161J-221	220	1/6W	CARBON	
	R702	QRD161J-221	220	1/6W	CARBON	
	R703	QRD167J-101	100	1/6W	CARBON	
	R820	QRD161J-221	220	1/6W	CARBON	
	R821	QRD161J-221	220	1/6W	CARBON	
	R822	QRD161J-221	220	1/6W	CARBON	
	R823	QRD161J-221	220	1/6W	CARBON	
	R824	QRD161J-221	220	1/6W	CARBON	
	R825	QRD161J-221	220	1/6W	CARBON	
	R826	QRD167J-101	100	1/6W	CARBON	
	R841	QRD167J-243	24K	1/6W	CARBON	
	R842	QRD167J-183	18K	1/6W	CARBON	
	R843	QRD167J-203	20K	1/6W	CARBON	
	R844	QRD167J-183	18K	1/6W	CARBON	
	R845	QRD167J-820	82	1/6W	CARBON	
	R871	QRD167J-273	27K	1/6W	CARBON	
	R872	QRD167J-223	22K	1/6W	CARBON	
	R873	QRD167J-303	30K	1/6W	CARBON	
	R874	QRD167J-103	10K	1/6W	CARBON	
	R876	QRD167J-473	47K	1/6W	CARBON	
	R877	QRD167J-752	7.5K	1/6W	CARBON	
	R879	QRD161J-221	220	1/6W	CARBON	
	R881	QRD167J-393	39K	1/6W	CARBON	
	R882	QRD167J-123	12K	1/6W	CARBON	
	R883	QRD167J-153	15K	1/6W	CARBON	
	RA201	QRD049J-103	10K	1/10W	R.NETWORK	
	VR271	QVAB79C-E53B	5K		VARIABLE	
	VR512	QVPA601-203A	20K		VARIABLE	
	VR513	QVPA601-203A	20K		VARIABLE	
	VR603	QVPA601-203A	20K		VARIABLE	
	VR604	QVPA601-203A	20K		VARIABLE	

OTHERS

△	ITEM	PART NUMBER	DESCRIPTION		AREA
	S226	ESP0001-018	TACT SWITCH(8)		
	S227	ESP0001-018	TACT SWITCH(7)		
	S228	ESP0001-018	TACT SWITCH(6)		
	S229	ESP0001-018	TACT SWITCH(5)		
	S230	ESP0001-018	TACT SWITCH(4)		
	S231	ESP0001-018	TACT SWITCH(3)		
	S232	ESP0001-018	TACT SWITCH(2)		
	S233	ESP0001-018	TACT SWITCH(1)		
	X201	ECX0060-000EM	RESONATOR		
	X301	ECX0169-344EA	RESONATOR		
△	CP101	ICP-N5	I.C. PROTECTOR	A	
△	CP101	ICP-N5	I.C. PROTECTOR	C	
△	CP101	ICP-N5	I.C. PROTECTOR	E	
△	CP101	ICP-N5	I.C. PROTECTOR	F	
	FL201	ELU0001-132	FL TUBE		
	FW101	EWR36B-40SST	FLAT WIRE(6PIN)		
	FW201	EWR36B-20SST	FLAT WIRE(6PIN)		
	FW202	EWR36B-30SST	FLAT WIRE(6PIN)		
	FW203	EWR33B-10LST	FLAT WIRE(3PIN)		
	FW801	EWR36B-10KST	FLAT WIRE(6PIN)		
	FW803	EWR37B-10KST	FLAT WIRE(7PIN)		
	FW831	EWR37B-10KST	FLAT WIRE(7PIN)		
	JT271	EMV7122-103	CONNECTOR		
	SW101	QSS1L22-E01	SLIDE SWITCH(VOLTAGE SELECTOR)		F

△ : SAFETY PARTS

OTHERS

△	ITEM	PART NUMBER	DESCRIPTION			AREA
		E3400-439	FELT SPACER			
		E70306-001	HEAT SINK			
		E70859-001	EARTH PLATE			
		E75819-001	SUPPORT HOLDER			
		E75820-001	SUPPORT HOLDER			
		SBSE3008Z	SCREW			
J201		EMV7123-035	CONNECTOR(3SPIN)			
J202		EMV7123-035R	CONNECTOR(3SPIN)			
J271		QMS6A20-E21H	HEADPHONE JACK			
J301		EMN00TV-21A	2P PIN JACK			
J451		GP1F32T	OPTICAL JACK			
J701		QMS3501-020	MINI JACK			
L271		EQL4004-1R0	INDUCTOR			
P101		QMCB001-E02H	AC SOCKET	A		
P101		QMCB001-E03H	AC INLET	D		
P101		QMCB001-E03H	AC INLET			
P101		QMCB001-E02H	AC SOCKET	E		
P101		QMCB001-E02H	AC SOCKET	F		
P501		EMV5109-010A	PLUG ASSY(10PIN)			
P502		EMV5109-004A	PLUG ASSY(4PIN)			
S201		ESP0001-018	TACT SWITCH(POWER)			
S202		ESP0001-018	TACT SWITCH(DISPLAY)			
S203		ESP0001-018	TACT SWITCH(REPEAT)			
S204		ESP0001-018	TACT SWITCH(INTRO)			
S205		ESP0001-018	TACT SWITCH(P.MODE)			
S206		ESP0001-018	TACT SWITCH(CALL)			
S207		ESP0001-018	TACT SWITCH(MEMORY)			
S208		ESP0001-018	TACT SWITCH(SIDEA/B)			
S209		ESP0001-018	TACT SWITCH(EDIT)			
S210		ESP0001-018	TACT SWITCH(EJECT)			
S211		ESP0001-018	TACT SWITCH(PLAY/PAUSE)			
S212		ESP0001-018	TACT SWITCH(STOP/CANCEL)			
S213		ESP0001-018	TACT SWITCH(▶)			
S214		ESP0001-018	TACT SWITCH(◀)			
S215		ESP0001-018	TACT SWITCH(OPEN/CLOSE)			
S216		ESP0001-018	TACT SWITCH(DISC 6)			
S217		ESP0001-018	TACT SWITCH(DISC 5)			
S218		ESP0001-018	TACT SWITCH(DISC 4)			
S219		ESP0001-018	TACT SWITCH(DISC 3)			
S220		ESP0001-018	TACT SWITCH(DISC 2)			
S221		ESP0001-018	TACT SWITCH(DISC 1)			
S222		ESP0001-018	TACT SWITCH(DISC 9)			
S223		ESP0001-018	TACT SWITCH(+10)			
S224		ESP0001-018	TACT SWITCH(10)			
S225		ESP0001-018	TACT SWITCH(9)			

△ : SAFETY PARTS

Accessories List

⚠	Part Number	Part Name	Q'ty	Description	Areas
	E30580-1951A E30580-1951A E30580-1952A E30580-1953A E30580-1953A	INSTRUCTION BOOK INSTRUCTION BOOK INSTRUCTION BOOK INSTRUCTION BOOK INSTRUCTION BOOK	1 1 1 1 1		A J EN C EF
	E30580-1953A E30580-1953A BT-51001-1 BT-20025K BT-20122	INSTRUCTION BOOK INSTRUCTION BOOK LIMITED WARRANTY CARD WARRANTY CARD WARRANTY CARD	1 1 1 1 1		U UT J C A
	BT-20122-1 BT-51006-1 BT-20044G BT20071A QMP25D0-183	STICKER SAFETY REGISTRATION CARD SAFETY SHEET SERVICE NETWORK POWER CORD	1 1 1 1 1		A J J C A
⚠	QMP1E00-183 QMP39F0-183 QMP39F0-183 QMP1E00-183 QMP7530-183	POWER CORD POWER CORD POWER CORD POWER CORD POWER CORD	1 1 1 1 1		C EF EN J U
⚠	QMP7530-183 EWP302-013K EWP805-009K E35497-022 E35497-022	POWER CORD SIGNAL CORD PLUG WIRE ASSY CAUTION SHEET CAUTION SHEET	1 1 1 1 1	220V 220V	UT U UT
⚠	E04056 E04056 E26072-005 E407273-001 RM-SX509U	SIEMENS PLUG SIEMENS PLUG MAGAZINE STICKER REMOTE CONTROLLER	1 1 1 1 1		U UT
	RM-SX507UBATC R6PRPA-2STSA R6PRPA-2STSA UM-3(DJ)-2PSA UM-3(DJ)-2PSA	BATTERY COVER BATTERY BATTERY BATTERY BATTERY	1 1 1 1 1		J C A EF
	UM-3(DJ)-2PSA UM-3(DJ)-2PSA UM-3(DJ)-2PSA E300196-010 E300196-010	BATTERY BATTERY BATTERY ENVELOPE ENVELOPE	1 1 1 2 2		EN U UT A C
	E300196-010 E300196-010 E300196-010B E300196-010 E300196-010	ENVELOPE ENVELOPE ENVELOPE ENVELOPE ENVELOPE	2 2 2 2 2		EF EN J U UT

The Marks for Designated Areas

J the U.S.A.

EF Continental Europe


No mark indicates all areas.

C Canada
U UniversalA Australia
UT Taiwan

EN Scandinavia

⚠ SAFETY PARTS

Packing Materials and Part Numbers



The Marks for Designated Areas

J	the U.S.A.	C	Canada
A	Australia	EN	Scandinavia
EF	Continental Europe	G	Germany
U	Universal Type	UT	Taiwan

No mark indicates all areas.

PK-XLM509TNJ(J,C)
 (E300383-503)
 PK-XLM509TNE(EN,EF,U,UT)
 (E300383-504)
 PK-XLM509TNA(A)
 (E300383-505)
 Packing Case

— MEMO —

— **MEMO** —