

SAFETY PRECAUTIONS**SERVICE WARNING**

Only qualified service technicians who are familiar with safety checks and guidelines should perform service work. Before replacing parts, disconnect power source to protect electrostatically sensitive parts. Do not attempt to modify any circuit unless so recommended by the manufacturer. When servicing the receiver, use an isolation transformer between the line cord and power receptacle.

SERVICING THE HIGH VOLTAGE AND CRT

Use EXTREME CAUTION when servicing the high voltage circuits. To discharge static high voltage, connect a 10K ohms resistor in series with a test lead between the receiver ground and CRT anode lead. DO NOT lift the CRT by the neck. Always wear shatterproof goggles when handling the CRT to protect eyes in case of implosion.

X-RAY RADIATION AND HIGH VOLTAGE LIMITS

Be aware of the instructions and procedures covering X-ray radiation. In solid-state receivers and monitors, the CRT is the only potential source of X-rays. Keep an accurate high voltage meter available at all times. Check meter calibration periodically. Whenever servicing a receiver, check the high voltage at various brightness levels to be sure it is regulating properly. Keep high voltage at rated value, NO HIGHER. Excessive high voltage may cause X-ray radiation or failure of associated components. DO NOT depend on protection circuits to keep voltage at rated value. When troubleshooting a receiver with excessive high voltage, avoid close contact with the CRT. DO NOT operate the receiver longer than necessary. To locate the cause of excessive high voltage, use a variable AC transformer to regulate voltage. In present receivers, many electrical and mechanical components have safety related characteristics which are not detectable by visual inspection. Such components are identified by a # on both the schematic and the parts list. For SAFETY, use only equivalent replacement parts when replacing these components.

GENERAL GUIDELINES

Perform a final SAFETY CHECK before returning receiver to customer. Check repaired area for poorly soldered connections, and check entire circuit board for solder splashes. Check board wiring for pinched wires or wires contacting any high wattage resistors. Check that all control knobs, shields, covers, grounds, and mounting hardware have been replaced. Be sure to replace all insulators and restore proper lead dress.

The listing of any available replacement part herein in no case constitutes a recommendation, warranty, or guarantee by SAMS Technical Publishing, LLC as to the quality and suitability of such replacement part. The numbers of the listed parts have been compiled from information furnished to SAMS Technical Publishing, LLC by the manufacturers of the specific type of replacement part listed.

Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein.

© 2005 SAMS Technical Publishing, LLC

9850 E. 30th St.
Indianapolis IN 46229
www.samswebsite.com

Printed in the United States of America 5 4 3 2 1

05PT03224



PHOTOFAC[®] GOLD

SET 5061

MODELS PT-61G42CV/LV/PV/TV/V/VV/XV (CHASSIS AEDP811)


INDEX

Important Parts Information	1
Miscellaneous Adjustments	1
Parts List	6
Placement Chart	1
<i>Safety Precautions</i>	1
Schematic Component Location	5
Schematic Notes	3
Schematics	
Audio	4
A/V Switching	4
Convergence	4, 5
PIP	3
Power Supply	3
System Control	3
Television	2
Test Equipment	6
Tuner Information	1

For a Complete List of Manuals,
Visit www.samswebsite.com

PANASONIC

Models PT-61G42CV/LV/PV/TV/V/VV/XV (Chassis AEDP811)

PANASONIC


Representative Model

**Essential coverage
for servicing a television receiver...**

- Schematics
- Component locations
- Parts list


Coverage includes these additional models and chassis:

Models	Chassis
PT-51G41V	AEDP811
PT-51G42CV/LV/PV/TV/V/VV/XV	AEDP811




SEPTEMBER 2005 SET 5061

PLACEMENT CHART




PLACEMENT CHART continued


X BOARD




LG BOARD




LB BOARD




K BOARD




D BOARD



LR BOARD



Y BOARD



(1) LOCATED ON BOTTOM OF BOARD

Important Parts Information

- Parts not listed in the parts list are commonly available at your local electronics parts retailer.
- The parts listed here are those not usually available from a well-stocked supply cabinet or bin.
- Where items may be replaced with equivalent parts, several alternates are shown from participating vendors.
- On the parts lists, safety items are marked with a # to remind you that only exact replacements are recommended for these items.
- When ordering parts, state the model number, part number, and description.

Obtaining Parts



Many of these parts are available from your local Sams authorized distributor or the manufacturer of the equipment. Call Sams for the name of your nearest distributor:

800-428-7267

Participating Vendors


Information on test equipment and replacement parts is listed in these pages for the following participating vendors.

- NTE Electronics, Inc. (NTE)
- Sencore, Inc.

A**TELEVISION SCHEMATIC****B**

C


TELEVISION SCHEMATIC continued



E


TELEVISION SCHEMATIC continued

F




G

TELEVISION SCHEMATIC continued




H



A


POWER SUPPLY SCHEMATIC

B




C

POWER SUPPLY SCHEMATIC continued




D




E

SYSTEM CONTROL SCHEMATIC




F



G

PIP SCHEMATIC




For SAFETY use only equivalent replacement part, see parts list.
→ Circuitry not used in some versions.
--- Circuitry used in some versions.
↓ Ground
m Chassis ground
△ Common tie point
Δ Taken from common tie point
3 Schematic CIRCUITTRACE® Voltage source tie point.
A → Cabling: Heavy lines reduce use of multiple lines.


Waveforms and voltages are taken from ground, unless otherwise noted.
Waveforms taken with triggered scope and colorbar signal.
Waveform voltage is peak to peak, Timebase is per division. Waveforms shown at 10 divisions.
Supply voltages maintained as seen at input.
Voltages measured with digital meter and a 1000μV RF signal, with colorbar pattern applied to antenna terminal.
Controls adjusted for normal operation.
Capacitors are 50 volts or less, 5% or greater unless noted.
Capacitor values are in microfarads unless noted.
Electrolytic capacitors are 50 volts or less, 20% or greater unless noted.
Resistors are less than 1W, 5% or greater unless noted.
Value in () used in some versions.
Measurements with switching as shown unless noted.
Rated voltage shown on zener diodes.

A

A/V SWITCHING SCHEMATIC



B




ADDITIONAL SCHEMATIC NOTES, SEE PAGE 3G

C


AUDIO SCHEMATIC

D

A



B



C




E

ADDITIONAL SCHEMATIC NOTES, SEE PAGE 3G





A PHOTOFAC STANDARD NOTATION SCHEMATIC
WITH CIRCUITTRACE®
© 2005 SAMS Technical Publishing, LLC

E

CONVERGENCE SCHEMATIC





C BOARD IS NOT REPAIRABLE

ADDITIONAL SCHEMATIC
NOTES, SEE PAGE 3GA PHOTOFAC STANDARD NOTATION SCHEMATIC
WITH CIRCUIT TRACE®

© 2005 SAMS Technical Publishing, LLC

F

IC7109
SUB CPU

81 T 82 T 83 T 84 T 85 T 86 T 87 T 88 T


G

CONVERGENCE SCHEMATIC continued

H

PANASONIC

MODELS PT-61G42CV/LV/PV/TW/V/W/XV (CHASSIS AEDP811)



A

CONVERGENCE SCHEMATIC continued

B

